

# BISSELL

# Uprights

Model: 35128

- 1.....BI-2137705.....Seal, Cone
- 2.....BI-2145957.....Motor
- 3.....BI-8807002.....Screws
- 4.....BI-5559192.....Motor Ring
- 5.....BI-3131116.....Motor Strap
- 6.....BI-3140400.....Chassis w/ rear wheels
- 8.....BI-3102036.....Clip, slide detent
- 9.....BI-3135715.....Lever, height adjust
- 10.....BI-3135725.....Slide
- 11.....BI-2101009.....Floor Brush Assy
- 12.....BI-2100600.....Belt
- 13.....N/A.....Front Wheel Assy
- 14.....BI-5559266.....Access Plate
- 15.....BI-2144421.....Upper Handle, w/ plug
- 16.....BI-2135100.....Plug Only
- 17.....BI-32013.....Paper Bag, style 2, micro, 3 pack
- 18.....BI-2107010.....Outer Bag Assy
- 19.....NLA.....Dirt Tube Assy
- 20.....BI-2131602.....Tool Rack
- 21.....BI-2109102.....Wand
- 22.....NLA.....Vacuum Hose
- 23.....NLA.....Upholstery Nozzle
- 24.....BI-2109108.....Crevice Tool
- 25.....BI-2101021.....Dusting Brush
- 26.....BI-2035100.....Knob, height adjustment
- 27.....BI-3142958.....Top Cover, w/ lens
- BI-7135510.....Lens Only
- 28.....BI-2130306.....Bumper
- BI-2102862.....Power Cord
- BI-5559125.....Switch, rocker
- BI-2137001.....Cord Wrap

