



Models: SB-12600, SB-12600C, SB-12601, SB-12680,
SB-126801, SB-12682, SB-12683, SB-12720, SB-12720C, SB-12760

Handle Assembly

- 1 BI-32018 Paper Bag, type SUB-3, 3 pack
- 2 BI-5554431 Handle Tube, w/ grip
- 2 BI-5554430 Handle Tube, w/ grip, 12680,12681
- 2 SI-663121903 Handle Tube, w/ grip, 12720,12720C,12760
- 3 SI-663043010 Handle Grip
- 4 BI-5554473 Lower Handle Assy, w/ seal
- 4 SI-663434901 Lower Handle Assy, w/ seal, 12680,12681
- 4 SI-663434904 Lower Handle Assy, w/ seal, 12720,12720C,
12760
- 5 N/A Bag Clip
- 6 N/A Dust Bag Assy, w/ clip
- 6 BI-5554474 Dust Bag Assy, w/ clip, 12680,12681,12682,
12683,12760
- 6 SI-663435903 Dust Bag Assy, w/ clip, 12720,12720C
- 7 BI-8807002 Screw
- 8 N/A Cord Cleat, w/ groove
- 8 N/A Cord Cleat, w/ groove, 12680,12681
- 9 N/A Screw, cord clamp
- 10 BI-7132420 Cord Clamp
- 11 BI-2805040 Handle Nut
- 12 BI-2807210 Handle Screw
- 13 BI-7103415 Handle Seal
- 14 N/A Power Cord
- SI-643616002 Hose Cleat, 12720,12720C,12760




Handle Assembly



- | | | | | | |
|----|------------------|---|----|------------------|--|
| 1 | N/A | Upper Handle Assy, 12650 | 13 | ... BI-8807002 | Screw, 1/2" |
| 1 | BI-5554248 | Upper Handle Assy, 12660,12800 | 14 | ... N/A | Lower Handle Assy |
| 1 | BI-5554249 | Upper Handle Assy, 12661,12770,12851 | 14 | ... N/A | Lower Handle Assy, 12661 |
| 1 | N/A | Upper Handle Assy, 14750,14750C,14760, 14850 | 14 | ... SI-662031910 | Lower Handle Assy, 12770,12851 |
| 2 | BI-7135105 | Handle End Plug | 15 | ... BI-32018 | Paper Bag, type SUB-3, 3 pack |
| 3 | BI-5554240 | Switch Cap, 12660,12661 | 16 | ... N/A | Cord Latch |
| 3 | BI-7135111 | Switch Cap, 14750,14750C,14760,14850 | 17 | ... BI-5554239 | Caddy, 12660,12661,14750,14750C,14760 14850 |
| 4 | N/A | Actuator, 12660,12661,14750,14750C, 14760,14850 | 18 | ... BI-8807205 | Screws, 12660,12661,14750,14750C,14760, 14850 |
| 5 | BI-7102650 | Wire Nut | 19 | ... BI-2807210 | Bolt |
| 5 | BI-7102651 | Wire Nut, 12770,12851 | 20 | ... BI-2805040 | Nut |
| 6 | BI-7108614 | Switch | 21 | ... N/A | Dust Bag Assy, w/ spring, 12650 |
| 6 | BI-5559125 | Switch, 12661,12770,12851 | 21 | ... N/A | Dust Bag Assy, w/ spring, 12660 |
| 7 | BI-7132420 | Cord Clamp | 21 | ... SI-662770904 | Dust Bag Assy, w/ spring, 12661 |
| 8 | BI-8807206 | Screw, cord clamp | 21 | ... N/A | Dust Bag Assy, w/ spring, 12770 |
| 9 | BI-5554750 | Power Cord, 20 ft | 21 | ... N/A | Dust Bag Assy, w/ spring, 12800 |
| 9 | BI-3102810 | Power Cord, 20 ft, 12770,12851 | 21 | ... SI-662770906 | Dust Bag Assy, w/ spring, 12851 |
| 10 | ... BI-7108432 | Plug Mount Spring | 21 | ... N/A | Dust Bag Assy, w/ spring, 14750,14750C, 14850 |
| 11 | ... BI-3102818 | Jumper Cord | 21 | ... SI-661884909 | Dust Bag Assy, w/ spring, 14760 |
| 12 | ... BI-7132962 | Switch Cover | 22 | ... BI-5554319 | Bag Spring, 12660,12661,14750,14750C,
14760,14850 |
| 12 | ... BI-7132963 | Switch Cover, 12661,12770,12851 | | | |

Handle Assembly




- | | | | | | |
|----|--------------------|--|----|--------------------|--|
| 1 | BI-7135105 | Handle End Plug | 13 | BI-3102818 | Jumper Cord |
| 2 | BI-5554249 | Upper Handle, 12662,12750,12751 | 14 | BI-7108432 | Plug Mount Spring |
| 2 | N/A | Upper Handle, 14100,14100C,14200 | 15 | BI-5554319 | Spring, 14100,14100C |
| 3 | N/A | Cord Latch | 16 | SI-662770901 | Dust Bag Assy, 12662 |
| 4 | BI-8807205 | Screw, flat head | 16 | SI-662770904 | Dust Bag Assy, 12750 |
| 5 | BI-3102810 | Power Cord, 20 ft, w/ strain relief, 12662, 12751 | 16 | N/A | Dust Bag Assy, 12751 |
| 5 | SI-971033102 | Power Cord, 20 ft, w/ strain relief, 12750 | 16 | N/A | Dust Bag Assy, 14100,14100C,14200 |
| 5 | N/A | Power Cord, 30 ft, w/ strain relief, 14100, 14100C,14200 | 17 | SI-662031910 | Lower Handle Assy, 12662,12751 |
| 6 | BI-5554437 | Caddy Seal, 12662 | 17 | N/A | Lower Handle Assy, 12750 |
| 6 | BI-7107710 | Caddy Seal, 12750,12751 | 17 | N/A | Lower Handle Assy, 14100,14100C,14200 |
| 6 | BI-7107711 | Caddy Seal, 14100,14100C,14200 | 18 | BI-7132963 | Switch Cover, 12662,12750,12751 |
| 7 | SI-662055903 | Tool Caddy, 12662,12750,12751 | 18 | BI-7132962 | Switch Cover, 14100,14100C,14200 |
| 7 | BI-5554239 | Tool Caddy, 14100,14100C,14200 | 19 | BI-5559125 | Switch, 12662,12750,12751 |
| 8 | BI-8807206 | Cord Clamp Screw | 19 | BI-7108614 | Switch, 14100,14100C,14200 |
| 9 | BI-7132420 | Cord Clamp | 20 | BI-8807002 | Screw, 1/2" |
| 10 | BI-2805040 | Nut | 20 | BI-32018 | Paper Bag, type SUB-3, 3 pack |
| 11 | BI-7103415 | Motor / Handle Seal, 12622,12750,12751 | 22 | N/A | Lower Handle, 12662 |
| 11 | SI-663937001 | Motor / Handle Seal, 14100,14100C,14200 | 22 | N/A | Lower Handle, 12750 |
| 12 | BI-2807210 | Bolt | 22 | N/A | Lower Handle, 12751,14100,14100C,14200 |

Models: SB-12600, SB-12600C, SB-12601, SB-12680, SB-12601, SB-12681,
SB-12682, SB-12683, SB-12720, SB-12720C, SB-12760

SB Series

Chassis Assembly




- 1 BI-5554042 Access Door, w/ seal
- 2 BI-7135101 Knob Height Adjustment
- 3 N/A Top Cover, 12600,12600C,12601
- 3 N/A Top Cover, 12680,12681,12682,12683
- 3 N/A Top Cover, 12720,12720C
- 3 N/A Top Cover, 12760
- 4 BI-7135702 Switch Pedal
- 5 BI-7108431 Spring Switch Pedal
- 6 BI-5559196 Handle Release Pedal
- 7 BI-8807002 Screw
- 8 BI-3131115 Strap
- 9 BI-7137705 Seal Cone
- 10 BI-5554115 Motor Assy, w/ cone
- 10 N/A Motor Assy, w/ cone, 12601,12683
- 10 BI-5554115 Motor Assy, w/ cone, 12680
- 11 BI-7108411 Access Door Spring
- 12 BI-7131110 Motor Ring
- 13 BI-8807203 Screw
- 14 N/A Washer
- 15 BI-2108421 Internal Slide Spring
- 16 BI-5554408 Chassis, w/ wheels
- 17 BI-3130306 Bumper
- 18 N/A 2-Position Rack
- 19 BI-7135711 Internal Slide
- 20 N/A Height Adjustment Slide, lower
- 21 BI-2101009 Floor Brush Assy
- 22 BI-32015 Belt, type SDB-4, 2 pack
- 23 BI-2149700 Front Wheel Assy
- 24 BI-5559266 Access Plate Assy

Models: SB-12650, SB-12660, SB-12661, SB-12662, SB-12750, SB-12751, SB-12770, SB-12800, SB-12851, SB-14100, SB-14100C, SB-14200, SB-14750, SB-14750C, SB-14760, SB-14850

SB Series

Chassis Assembly



Models: SB-12650, SB-12660, SB-12661, SB-12662, SB-12750, SB-12751, SB-12770, SB-12800, SB-12851, SB-14100, SB-14100C, SB-14200, SB-14750, SB-14750C, SB-14760, SB-14850

1	N/A	Top Cover Assy, 12650	15	BI-7137705	Cone Seal
1	N/A	Top Cover Assy, 12660	16	BI-5559069	Light Bulb
1	N/A	Top Cover Assy, 12661,12662,12800	17	N/A	Washer
1	N/A	Top Cover Assy, 12750	18	BI-8807203	Screw
1	N/A	Top Cover Assy, 12751	19	BI-2108421	Internal Slide Spring
1	N/A	Top Cover Assy, 12770	20	N/A	Height Adjustment Rack
1	N/A	Top Cover Assy, 12851	20	N/A	Height Adjustment Rack, 12851
1	N/A	Top Cover Assy, 14100,14100C,14200	20	BI-7131103	Height Adjustment Rack, 14100,14100C, 14200
1	N/A	Top Cover Assy, 14750,14750C	21	BI-5554122	Height Adjustment, lower
1	N/A	Top Cover Assy, 14760	21	BI-3135715	Height Adjustment, lower, 12662,12751, 12770,12851,14100,14100C,14200
1	N/A	Top Cover Assy, 14850	21	BI-5554353	Height Adjustment, lower, 14750,14750C, 14760,14850
2	BI-5554042	Tool Door Assy, w/ seal	22	BI-5554117	Internal Slide
3	BI-2035100	Lens	22	BI-7135719	Internal Slide, 12770,12851,14100,14100C, 14200
4	BI-2035100	Adjustment Knob	23	BI-2108410	Auto Slide Spring
4	BI-2035100	Adjustment Knob, 12660,12661,12662,12800	24	BI-5557266	Access Plate
4	BI-2035100	Adjustment Knob, 12751,12770,12851,14100 14100C,14200	24	BI-5557266	Access Plate, 12751,12851
5	BI-3130306	Bumper	24	BI-5557266	Access Plate, 12800
5	BI-7130305	Bumper, 14100,14100C,14200,14750,14750C 14760,14850	24	BI-7133002	Access Plate, 14100,14100C,14200
6	BI-2101009	Brush Roll, w/ belt	24	BI-7133002	Access Plate, 14750,14750C,14760,14850
6	BI-5554181	Brush Roll, w/ belt, 14100,14100C,14200	25	BI-7101005	Bare Floor Brush, 14100,14100C,14200
6	SI-661912904	Brush Roll, w/ belt, 14750,14750C,14760, 14850	26	BI-7108415	Bare Floor Spring, 14100,14100C,14200
7	BI-32015	Belt, type SDB-4, 2 pack	27	BI-7135705	Bare Floor Cam, 14100,14100C,14200
8	N/A	Front Wheel Assy	28	BI-5554522	Seal-Motor, rubber, 14100,14100C,14200
8	BI-2149700	Front Wheel Assy, 12662,12751,12770,12851 14100,14100C,14200		BI-5554198	Dirt Tube Seal
9	BI-5554408	Chassis, w/ rear wheels		N/A	Clip, 2 position
9	BI-5554408	Chassis, w/ rear wheels, 12662,12751			
9	BI-5554408	Chassis, w/ rear wheels, 12770,12851			
9	BI-5554411	Chassis, w/ rear wheels, 14100,14100C, 14200			
9	BI-5554411	Chassis, w/ rear wheels, 14750,14750C, 14760			
9	BI-5554411	Chassis, w/ rear wheels, 14850			
10	BI-5559196	Handle Release Pedal			
11	BI-5559152	Motor Ring			
12	BI-5554105	Motor Assy			
12	BI-5554105	Motor Assy, 12660			
12	BI-5554114	Motor Assy, 12662,12751			
12	BI-5554114	Motor Assy, 12770,12851			
12	BI-0145954	Motor Assy, 14100,14100C,14200			
13	BI-8807002	Screw, 1 1/2"			
14	BI-3131115	Motor Strap			