

Upper Casting Assembly


The Boss
Plus

Models: 2101A/AT/B, 2105A/B, 2107A, 2109A, 2118A/B, 2122A/B, 2124A, 2125A, 2134B/BT/BT/D/DT/E/ET

- 1..... E-380542.....Grip Assy
- 2..... E-53143.....Screw, 10 pk
- 3..... E-143021.....Adjustment Knob, 2101A/AT/B,2105A/B,
2122A/B
- 3..... E-143022.....Adjustment Knob, 2118A/B
- 1..... E-380532.....Adjustment Knob, 2125A
- 4..... E-53147.....Screw, 10 pk
- 5..... E-25729A6.....Slide Cover
- 6..... N/A.....Adjustment Slide
- 7..... E-268083.....Switch Button
- 8..... E-540052.....Hood Assy, rose dust, 2101A/AT/B
- 8..... E-540053.....Hood Assy, deja blue, 2105A/B
- 8..... E-540351.....Hood Assy, dry rose, 2107A
- 8..... N/A.....Hood Assy, lt. periwinkle, 2109A
- 8..... N/A.....Hood Assy, frost white, 2118A/B
- 8..... E-540054.....Hood Assy, salmon, 2122A/B
- 8..... E-542496.....Hood Assy, 2124A
- 8..... E-5400510.....Hood Assy, 2125A
- 8..... N/A.....Hood Assy, millstone, 2134B/BT/D/DT/E/ET
- 9..... E-141931.....Lens, 2101A/AT/B,2105A/B
- 9..... E-272141.....Lens, 2134B/BT/D/DT/E/ET
- 10..... E-37989.....Clip, switch
- 11..... E-137385.....Switch, step-on
- 12..... E-601921.....Wire Nut, 5 pk,
- 13..... E-35958A.....Light Socket Assy
- 14..... E-40009A.....Bulb
- 15..... E-5323813.....Screw, 10 pk
- 16..... E-5323814.....Screw, 10 pk
- 17..... E-46713.....Wire Clip
- 18..... E-54773.....Motor Assembly
- 18..... E-5435211.....Motor Assembly, 2109A,2124A,2125A,2134E/ET
- 18..... E-545591.....Motor Assembly, 2134D/DT
- 19..... E-38067.....Air Separator, 2109A,2125A
- 19..... N/A.....Air Separator, 2134D/DT/E/ET
- 20..... E-55296.....Wire & Terminal
- 21..... E-30517.....Motor Seal Gasket
- 22..... E-24834A3.....Foot Pedal
- 23..... N/A.....Spring, foot pedal, 5 pk
- 24..... E-5323814.....Screw, 10 pk
- 25..... E-53140.....Clamp & Screw Assy, 6 pk
- 26..... E-48642.....Set Screw
- 27..... E-375901.....Bushing Bracket
- 28..... E-532287.....Bag Screw
- 29..... E-36263.....Wheel Cover
- 30..... E-5345612.....Base Assy, black, 2101A/AT/B,2105A/B,2118A/B,
2122A/B
- 30..... E-5345621.....Base Assy, white, 2107A,2109A,2124A,2134B/BT/
D/DT/E/ET
- 30..... E-544082.....Base Assy, frost white, 2125A
- E-24964A1.....Cam, right side
- E-24965A1.....Cam, left side
- E-53118.....Rivet, 10 pk
- E-53133.....Washer, 10 pk
- 31..... E-532155.....Screw, 10 pk
- 32..... E-532287.....Screw, 2125A
- 33..... E-382881.....Clamp, 2125A
- 34..... E-147631.....Bellows, 2125A

ATTACHMENTS

- N/A.....Hose Assembly
- E-26708119N.....Crevice Tool
- E-535305.....Upholstery Nozzle
- E-534547.....Dusting Brush
- E-545053.....Curved Wand



EUREKA UPRIGHTS




2100 Series

LOWER CASTING ASSEMBLY


The Boss Plus

Models: 2101A/AT/B, 2105A/B, 2107A, 2109A, 2118A/B, 2122A/B, 2124A, 2125A, 2134B/BT/BT/D/DT/E/ET

- 1.....N/A.....Furniture Guard,
- 1.....E-363423.....Furniture Guard, frost white, 2107A,2109A
- 1.....N/A.....Furniture Guard, 2118A
- 1.....N/A.....Furniture Guard, 2134B/BT/D/DT/E/ET
- E-285041.....Furniture Guard, clear, 2125A
- 2.....E-358582.....Rear Wheel
- E-26242119N.....Rear Wheel, 2125A
- E-60161.....Rear Wheel & Axle, 2125A
- E-53110.....Washer, 10 pk, 2125A
- 3.....E-47562.....Rear Axle
- 4.....E-53111.....Clip, 10 pk
- E-53201.....Clip, 2125A, 10 pk
- 5.....E-5323811.....Screw, clip, 10 pk
- 6.....E-530762.....Axle Spring, 6 pk
- E-53121.....Pushnut, 2125A
- 7.....E-35859A1.....Front Wheel
- 8.....E-35947A.....Front Axle
- 9.....E-30563A.....Belt, sold each
- 9.....E-52100.....Belt, 2 pack
- 10.....E-465384.....Gasket
- 11.....E-259221.....Bottom Plate
- E-533981.....Brush Roll, complete, VG2, hex end, 12", steel




BAG ASSEMBLY



- E-541334..... Bag Assy, zipper, grey/white, Tietex, 2 screw coupling
- E-5397717..... Bag Assy, zipper, drk blue/mauve "splash", "EUREKA triple filter" logo, 2 screw coupling
- E-5397717..... Bag Assy, zipper, red/black/grey "speckle" Tietex, "EUREKA triple filter" logo, 2 screw
- E-47722..... Spring
- E-541751..... Adapter, Sleeve & Gasket Assy
- E-36968..... Gasket
- E-52320..... Paper Bag, 3 pack
- E-54924..... Paper Bag, 9 pack
- E-57695..... Paper Bag, "FilterAire", 3 pack

DIRT CUP ASSEMBLY (2125A)



- E-601221.....Dirt Cup Assy, with bag
- 1.....E-553991.....Cover Pin
- 2.....E-147651.....Bag Flange
- 3.....E-38289.....Gasket
- 4.....E-545611.....Dirt Cup Support & Latch
- 5.....E-262662.....Clamp
- 6.....E-57711.....Steel Ring
- 7.....E-578661.....Snap Hook
- 8.....N/A.....Bag Assy
- E-58223.....Bag Gasket
- 9.....E-01959313N.....Dirt Cup

EUREKA UPRIGHTS

2100 Series


HANDLE ASSEMBLY

The Boss
Plus

Models: 2101A/AT/B, 2105A/B, 2107A, 2109A, 2118A/B, 2122A/B, 2124A, 2125A, 2134B/BT/BT/D/DT/E/ET

Handle for Models:


2101A/AT/B, 2118A/B, 2134B/BT/D/DT/E



- 1..... E-5323813.....Screw, 10 pk
- 2..... E-56815.....Washer
- 3..... E-56539.....Spring
- 4..... E-270362.....Cord Retainer, upper handle, black
- 5..... N/AHandle Cap, black
- 6..... E-270362.....Upper Handle Assy
- 7..... E-266591.....Handle Connector
- 8..... E-016812.....Lower Handle Tube
- 9..... E-535365.....Snap Pin, 10 pk
- 9..... E-535363.....Snap Pin, 10 pk, 2134B/BT/D/DT/E
- 10..... NLACord Assy, tobacco, 2101A/AT/B
- 10..... E-273821.....Cord Assy, black, 2118A/B,2134B/BT/D/DT/E
- 10..... E-530891.....Strain Relief Bushing, 10 pk
- 11..... E-540921.....Handle Socket Assy, 2101A/AT/B,2118A
- 11..... E-541241.....Handle Socket Assy, 2118B
- 12..... E-37157.....Shield
- 13..... E-53145.....Bolt, 10 pk
- 14..... E-531981.....Screw & Nut Assy, 6 pk
- 15..... E-5323813.....Screw, 10 pk
- 16..... E-532135.....Nut, 10 pk

Handle for Models:

2105B, 2107A, 2109A, 2122A/B, 2124A, 2125A



- 1..... E-352938.....Handle Grip
- 2..... E-2532920.....Upper Handle Assy
- 2..... N/AUpper Handle Assy, 2109A
- 2..... E-2532924.....Upper Handle Assy, 2125A
- E-360521.....Switch, rocker, 2109A
- 3..... E-369652.....Cord Hook, upper
- 3..... N/ACord Hook, upper, 2109A
- 3A..... E-135212.....Cord Hook, lower, 2124A,2125A
- 4..... E-126378.....Lower Handle Assy
- 4..... E-127943.....Lower Handle Assy, 2109A
- 4..... N/ALower Handle Assy, 2125A
- 5..... E-531981.....Screw & Nut Set, 6 pk
- 6..... E-530891.....Strain Relief Bushing, 10 pk
- 7..... NLACord Assembly, 2105B,2125A
- 7..... E-252426.....Cord Assembly, 2109A
- 7..... E-396302.....Cord Assembly, 2124A
- E-3605010.....Handle Cord, 2109A
- 8..... E-360972.....Sleeve
- 9..... E-541241.....Handle Socket Assy, 2105B
- 9..... E-540922.....Handle Socket Assy, 2107A,2109A
- 9..... E-271372SV.....Handle Socket Assy, 2122A/B,2124A,2125A
- 10..... E-532135.....Nut, 10 pk
- 11..... E-5323813.....Screw, 10 pk
- 12..... E-53145.....Bolt, 10 pk
- 13..... E-37157.....Shield
- 13..... E-36439.....Shield, 2124A