


# EUREKA UPRIGHTS

# 6400 Series

Models: 6404AT (Boss), 6405ATX, 6410AT, 6425AT (Quiet Kleen), 6426ATV, 6435AT

EXCALIBUR



# EUREKA UPRIGHTS

# 6400 Series

EXCALIBUR

Models: 6404AT (Boss), 6405ATX, 6410AT, 6425AT (Quiet Kleen), 6426ATV, 6435AT

1	E-54707	Push-On Nut, 10 pk	52	N/A	Motor Cover
2	E-58244	Screw, height adjustment	53	E-27536A	Final Filter
3	E-273721	Adjustment Lever	53	E-27536A	Final Filter, 6404,6425,6435
4	E-2748313SV	Adjustment Cover & Graphics	53	E-60140	HEPA Filter, 6405,6426
4	E-274833	Adjustment Cover & Graphics, 6435	54	E-27604B2	Rear Housing
5	E-547055	Hood & Graphics Assy, 6404,6405	55	E-5323828	Screw, 10 pk
5	E-547051	Hood & Graphics Assy, 6410,6425	56	E-149091	Carrying Handle
5	N/A	Hood & Graphics Assy, 6426	57	E-5323832	Screw, 10 pk
5	E-547054	Hood & Graphics Assy, 6435	58	E-149671	Access Door
6	E-532384	Screw, 10 pk		E-14966	Gasket, access door
6	E-38389A1	Pulley Cover, 6404,6405,6425,6426,6435	60	E-546691	Screw, 10 pk
7	E-383891	Pulley Cover, 6410	61	E-382431	Rear Housing Assy
8	E-5323811	Screw, 10 pk	62	E-27384	Filter
9	E-57879	Motor Strap	63	E-27385	Frame, filter
10	E-277491	Lower Cord Assy, 6404,6405	64	N/A	Diverter Valve Door
10	E-274121	Lower Cord Assy, 6410,6425,6426,6435	64	E-27666	Diverter Valve Door, 6404,6405,6425,6435
11	E-532142	Wire Nut, 10 pk	65	E-5323833	Screw, 10 pk
12	E-543434	Motor Assy, for brush roll	66	E-27345	Diverter Arm
13	E-467131	Wire Tie, 6410	67	E-54710	Spring, 5 pk
13	E-46713	Wire Tie	68	E-27463	Motor Fan Gasket
14	E-58421	Wire Shield	69	E-5323835	Screw, 10 pk
15	E-547069	Base & Cam Assy		E-27686	Sound Foam, 6425,6435
16	E-27376	Lamp Socket & Harness Assy	70	E-02019A1SV	Upper Handle Assy
17	E-532384	Screw, 10 pk	71	E-5323837	Screw, 10 pk
18	E-530762	Axle Spring	72	E-27514	Latch
19	E-5323811	Screw, 10 pk	73	N/A	Bag Cover & Graphics, 6404
20	E-604672	Brush Roll Assy	73	E-148828	Bag Cover & Graphics, 6410,6425
	E-27209A	Cap, brush roll, 6410	73	E-606541	Bag Cover & Graphics, 6426
22	N/A	Bottom Plate	73	E-606547	Bag Cover & Graphics, 6435
22	E-02235119N	Bottom Plate, 6426	74	N/A	Cord Retainer Release, 6410,6435
23	E-38407	Cap, foot pedal	74	N/A	Cord Retainer Release, 6405,6426
24	E-27405	Foot Pedal	75	E-383942	Supply Cord, 6404
25	E-58298	Pin, foot pedal	75	E-383943	Supply Cord, 6410,6425,6435
26	E-54708	Spring, 10 pk	75	E-383946	Supply Cord, 6426
27	E-467132	Cable Tie	76	E-383483	Switch, rocker
28	E-148811SV	Bellows	76	E-27871	Switch, rocker, 6405,6426
29	E-5323811	Screw, 10 pk	77	E-54711	Spring
30	E-58295	Cable Clamp	78	E-532381	Screw, 10 pk
30	E-58430	Cable Clamp, 6405,6426	79	E-567501	Clip, bag indicator
31	E-262703	Rear Wheel	80	E-377612	Bag Indicator
32	E-38392	Axle		E-58183	Paper Bag, style 'Y', 3 pack
33	E-55684	Prong Lock Retainer, 6410		E-54686	Cloth Bag, style 'Y', commercial
33	E-54709	Prong Lock Retainer	<b>Attachments</b>		
34	E-5323811	Screw, 10 pk	E-60168	Hose Assembly, complete	
35	E-57940	Headlight Lamp, 6410,6425	E-60165	Hose, w/ coupling only, 6404,6425,6435	
36	E-273743	Lens, 6404,6405	E-383811	Bleeder Ring, 6404,6425,6435	
36	E-273741	Lens, 6410, 6425,6426,6435	E-149902	Wand, w/ bleeder	
37	E-35859A1	Wheel, front	N/A	Wand, straight	
38	E-38457	Axle, front	E-26708119N	Crevice Tool	
39	E-53201	Clamp, axle	E-54782	Upholstery Nozzle	
40	E-30563A	Belt, sold ea	E-545053	Dusting Brush	
41	E-532142	Wire Nut, 10 pk	E-58068	Hardware Package, 6404,6425	
41	E-601921	Wire Nut, 10 pk, 6426			
42	E-274111	Upper Cord Assy, w/ switch			
42	E-27898	Upper Cord Assy, w/ rocker switch, 6405,6426			
43	E-27410	Micro Snap Switch			
44	E-5323834	Screw, 10 pk			
45	E-38410	Motor Shield			
46	E-600321	Dirt Chute Cover			
46	E-600322	Dirt Chute Cover, 6405,6426			
47	E-5323828	Screw, 10 pk			
48	E-532384	Screw, 10 pk			
49	E-55463	Motor Stack Gasket			
50	E-60012	Motor Assy, suction			
51	E-5323828	Screw, 10 pk			