


EUREKA UPRIGHTS

7700 / 7800 Series

Models: 7735AT, 7745AT, 7822ATS2

DIRECT AIR UPRIGHT


- 1 E-609541 Hose Assembly Complete
- 1 E-610242 Hose Assembly Complete, 7822ATS2
- 2 E-392711 Upper Handle Assy
- 2 E-386874 Upper Handle Assy, 7822ATS2
- 3 E-283701 Cord and Switch Box Assy
- 3 E-276741 Cord and Switch Box Assy, 7822ATS2
- 4 E-6020811 Bag Assembly, 7735AT
- 4 E-6020812 Bag Assembly, 7745AT
- 4 E-6020815 Bag Assembly, 7822ATS2
- 5 E-140703 Straight Wand
- 6 E-609701 Hood Assembly, 7735AT
- 6 E-609702 Hood Assembly, 7745AT
- 6 E-601626 Hood Assembly, 7822ATS2
- E-15583313N Lens, 7745AT
- E-546692 Screw, lens, 7745AT
- E-579402 Headlight, 7745AT
- 7 E-38822SV Attachment Cover Assy
- 8 E-28342288N Height Adjustment Knob
- 8 E-28342A288N Height Adjustment Knob, 7822ATS2
- 9 E-610921 Brush Roll Assembly
- 9 E-602441 Brush Roll Assembly, 7822ATS2
- 10 E-15325288N Furniture Guard
- 10 E-15350A288N Furniture Guard, 7822ATS2
- 11 E-54312A Belt, 2 pack
- 11 E-61120 Belt, 2 pack, long life, 7822ATS2
- 12 E-391031SV Bottom Plate Assy
- 12 E-391032SV Bottom Plate Assy, 7822ATS2
- 13 E-57569 Felt Gasket
- 14 E-575671 Front Axle
- 15 E-38236A119N Front Wheel
- 15 E-38236B119N Front Wheel, 7822ATS2
- 16 E-60160 Screw, 10 pk
- 17 E-27793A119N Wheel Carriage
- 18 E-531973 Screw, 10 pk
- 19 E-6016312 Base Assembly, 7735AT
- 19 E-601637 Base Assembly, 7745AT
- 19 E-601638 Base Assembly, 7822ATS2
- 20 E-27794119N Rear Wheel
- 21 E-58814 Rear Axle
- 22 E-36407A Axle Spring, 7735AT
- 22 E-530762 Axle Spring, 7745AT,7822ATS2
- 23 E-15548313N Motor Bracket
- 24 E-27799288N Handle Release Pedal
- 25 E-54379103 Motor Assembly, 7735AT
- 25 E-54379104 Motor Assembly, 7745AT
- 25 E-54379112 Motor Assembly, 7822ATS2
- E-38873B Valve Assy, 7822ATS2



EUREKA UPRIGHTS

7700 Series

Models: 7735AT, 7745AT, 7822ATS2



- 1 Muffler Cover Assy, only with #2
- 2 E-38808 Lower Handle Assembly
- 2 E-2775526 Lower Handle Assembly, 7822ATS2
- 3 E-28013119N Cord Release Hook
- 4 E-392711 Upper Handle Assembly
- 4 E-386874 Upper Handle Assembly, 7822ATS2
- 5 E-272071 Handle Cap
- 6 E-601921 Wire Splice, 5 pk
- 7 E-531973 Screw, 10 pk
- 8 E-28283119N Switch Box, rear
- 9 E-28321119N Switch Box, front
- 10 E-28073A Rocker Switch
- 11 E-3868022 Cord & Terminal Assembly
- 12 E-393001 Lower Cord & Terminal Assembly
- 13 E-6020811 Bag Assembly, 7735AT
- 13 E-6020812 Bag Assembly, 7745AT
- 13 E-6020815 Bag Assembly, 7822ATS2

- 14 E-5323813 Screw, 10 pk
- E-27796288N Switch Pedal, 7822ATS2

ATTACHMENTS

- E-382392 Hose Adaptor
- E-27858A119N Hose Adaptor, 7822ATS2
- E-37057A3 Hose Coupling
- E-609541 Hose Assembly, complete
- E-610242 Hose Assembly, complete, 7822ATS2
- E-57802 Paper Bag, type U, 3 pk
- E-26708119N Crevice Tool
- E-61037 Dusting Brush
- E-61037 Combination Tool, 7822ATS2
- E-702041 Hardware Package
- E-59015 Hardware Package, 7822ATS2