

• HARD COVER ASSEMBLY

- 1 E-266032 Cord Release Button
- 2 E-601921 Wire Nut, 5 pk
- 3 E-376451 Lead
- 4 E-37588 Cord Release Actuator
- 5 N/A Push Lever
- 6 E-54383 Push-On Nut
- 7 E-37589 Crank
- 8 E-53291 Screw, 10 pk
- 9 E-531971 Screw, 10 pk
- 10 E-531973 Screw, 10 pk
- 11 E-016411 Back Cover
- 12 E-266052 Switch Button
- 13 E-55446 Nut, switch
- 14 E-137385 Switch Assembly
- 15 N/A Cover & Nameplate Assembly
E-377332 Nameplate
- 16 E-562031 Cord Guide
- 17 N/A Cord Reel Assembly
- 18 E-016431 Support Plate
- 19 E-531971 Screw, 10 pk
- 20 N/A Screw, 10 pk
- 21 E-531974 Screw, 10 pk

