




## Closure Plates




N/A White - 1 Spd. - Toggle Switch  
 42227098 White - 1 Spd. - Slide Switch  
 42227090 White - 2 Spd. - Slide Switch



37226052 White - Toggle Switch & Slide Switch




N/A Toggle Switch & Power Nozzle  
 42227098 White - Slide Switch & Power Nozzle




36153009 Latch Ring


## Cord Reels



**Dimension**  
**46831025 Cord Reel**  
 1. 46383308 Attachment Cord



**Portable & Celebrity I & II**  
**46831015 Cord Reel Comp.**  
 1. N/A Cord Reel Ratchet  
 2. 46383303 Attachment Cord  
 3. N/A Detent Spring



**Spirit, Celebrity III & IV & Concept**  
**46831106 Cord Reel Comp.**  
 1. 46383308 Attachment Cord  
 2. 46831076 Commutator Block

**Spectrum/Futura/PowerMAX**  
**41911014 Cord Reel Comp.**  
 46383288 Attachment Cord

