


Models: LB8500



Models: LB8500

1	NLA	Housing assembly	55	NLA	Nut, axle acorn 3/8
2	NLA	Handle tube	56	O-095321201	Motor kit
3	O-5200302	Upper handle assembly	57	O-5200408	Cord, power handle SJTO W-A
4	O-097530102	Helping hand grip	58	NLA	Closed loop connector #8
5	O-5200400	Switch handle release	59	NLA	Wire nut, orange
6	O-030047601	Screw grip	60	O-030056601	Nut, 5/8 x 18 jam
7	NLA	Cover box	61	O-5321401	Flywheel plate
8	NLA	Screw, #6 x 1/2 flat head	62	O-5316301	Spacer
9	O-5200417	Relay	63	O-5316101	Bearing
10	O-5200402	Socket	64	O-5316201	Retainer bearing
11	NLA	Heyco 9068	65	O-5316001	Plug bearing
14	O-5200403	Cord, Power	66	O-030056701	Cap screw, bearing plug mounting
15	NLA	Bolt, 1/4 x 20 x 1 1/2"	67	O-095324651	Assembly, pan bottom
16	O-030052601	Nut, 1/4 x 20 lock	68	O-030056801	Screw, Pan
17	NLA	Bolt, 1/4 x 20 x 1 1/4	69	O-5200414	Circuit board assembly
18	NLA	Hook, upper cord wrap	70	O-5321801450	Bumper
19	NLA	Body, upper cord wrap	71	NLA	Magnets, flexible
20	NLA	Spring, quick release cord wrap	72	NLA	Jig latch bolt
21	NLA	Ball, delrin 1/4" upper cord wrap	73	O-5321901	Pivot
23	NLA	Bolt, 1/4 x 20 x 1", upper cord wrap hook to body	74	NLA	Post circuit board mounting
24	NLA	Bolt, 1/4 x 20 x 4 1/4", lower cord wrap	75	NLA	Support circuit board mounting
25	O-53269010327	Pad holder	76	NLA	Bracket bottom pan
26	NLA	Lower cord wrap & hook	77	NLA	1/8" pop rivet socket
27	NLA	Heyco solenoid	78	NLA	Flat washer #6 socket
28	O-5200404	Solenoid	79	NLA	CD10M 3/5" round magnet
29	O-5320201	Locking pin	80	NLA	Rivet, 5/32 bracket mounting pan
30	NLA	Washer, 3/8 x 3/4 x .052, teflon	81	NLA	Rivet, 3/16 swing arm mounting
31	NLA	Washer 3/8 x 3/4 x 1/16, flat	82	NLA	Swing arm bottom pan
32	NLA	Nut, 3/8 x 24, locking bracket	83	NLA	Heyco motor junction box
33	NLA	Bracket locking mechanism	84	NLA	1/4 x 20 nut 5/16 heyco
34	NLA	Boot	85	NLA	Heyco 5/16" power cord
35	O-030052001	heyco 1200	86	NLA	1/4" quick slide
36	NLA	Heyco sensor cable	87	O-030057301	Washer, plastic
37	O-5200309	Sensor frame	88	O-030057501	Washer, lock 3/8
38	NLA	Sensor circuit board	89	O-030057801	Washer, lock motor shaft
39	NLA	Heyco snap rivet	90	NLA	Bolt, motor
40	NLA	Assembly, hall sensor		NLA	Dust Shield
41	NLA	Cable holder, 3/16" sensor pkg		NLA	Owner's manual (LB8500)
42	NLA	Screw, 8 x 32 x 3/8", sensor cable wrap			
43	NLA	Nut, 8 x 32, sensor cable wrap			
44	NLA	ScREW, 10 x 24 x 1 1/4", sensor mounting			
45	NLA	Arc, left			
46	NLA	Arc, right			
47	O-030056001	bolt, 1/4 x 20 x 2 1/2, ground			
48	O-030057201	Washer, plastic			
49	O-030056101	Washer, ground 1/4 TRB411			
50	O-030056201	Bearing, thrust 1/4 NTA441			
51	O-53210010327	Bearing, pivot			
52	O-030053501	Screw, #10 x 24 x 7/16" patch			
53	NLA	wheels			
54	NLA	Axle, 3/8 x 2 5/8"			