


PANASONIC


Models: MC-UG371

BODY



Index	Part No.	Description
1	P-11237	Dust Compartment
2	P-8913	On/Off Switch
3	P-0698	Cord Stopper
4	P-6140	Screw (cord stopper), 10 pack
5	P-111595	Power cord
6	P-11377	Connector (wire crimp), 10 pack
7	P-111748	Packing (dust container), 2 pack
8	P-111749	Switch Cover
9	P-111752	Packing (switch cover)
10	P-6140	Screw (switch cover), 10 pack
11	P-7301	Handle Screw
12	P-2117	Nut
13	P-375	Secondary Filter (foam)
14	P-0114	Wheel
15	N/A	Shaft (wheel)
16	N/A	Stopper (wheel)
17	P-6115	Washer (wheel)
18	P-11376	Dust Bag (Type U6)
19	P-111755	Suction Inlet
20	P-11430	Motor Case
21	P-111496	Filter (motor case)
22	P-111497	Packing (motor case)
23	P-8172	Screw (motor case)
24	P-11269	Fan Motor Unit
25	P-10670	Noise Suppressor
26	P-11378	Motor Support Rubber (rear)
27	N/A	Motor Support Rubber (front)
28	P-3820	Wire Cord
29	P-111776	Handle Tube
30	P-111499	Handle Grip (left)
31	P-11247	Handle Grip (right)
32	P-6140	Screws (handle grip)
33	P-111758	Upper Cord Storage Hook
34	P-11379	Lower Cord Storage Hook
35	P-43096	Screw (lower cord storage hook)
36	P-11242	Extension Cord
37	P-00104	Wire Tie
38	P-11380	Dust Cover
39	P-10776	Protector
40	P-10415	Blue Protector Spring
41	P-111672	Protector Cover
42	P-111500	Wand Holder
43	P-6140	Screw (wand holder)
44	P-6140	Screw (suction inlet)
45	P-6106	Insulator Packing (handle screws)
46	P-11381	Lead Assembly
47	P-6088	Dusting Brush
48	P-6069	Crevice Tool
49	P-60104	Extension Wand
50	P-11382	Latch, Dust Cover
51	P-111569	Lead Wire

NOZZLE HOUSING



Index	Part No.	Description
1	P-11383	Nozzle Housing
2	P-10819	Shaft (plastic)
3	P-11234	Furniture Guard
4	P-58	Spring (pedal)
5	P-6140	Screw (pedal spring)
6	P-11369	Belt
7	P-11249	Lower Plate
8	P-6140	Screw
9	N/A	Window Cover
10	P-10304	Nozzle Hose
11	P-111744	Agitator Unit
12	P-43	Belt Cover
13	P-111746	Slider Support