


PANASONIC

Models: MC-UG471

BODY



PANASONIC

Models: MC-UG471

BODY

| Index | Part No. | Description |
|-------|----------|----------------------|
| 1 | P-11384 | Dust Compartment |
| 2 | P-11385 | Dust Cover |
| 3 | P-111647 | Wand Holder |
| 4 | P-10451 | On/Off Switch |
| 5 | P-11386 | Lead Wire (white) |
| 6 | P-11387 | Lead Wire (black) |
| 7 | P-10776 | Protector |
| 8 | P-11388 | Protector Spring |
| 9 | P-10661 | Protector Cover |
| 10 | P-11389 | Body Packing Right |
| 11 | P-11390 | Body Packing Left |
| 12 | P-11391 | Motor |
| 13 | P-11392 | Motor Support |
| 14 | P-111569 | Lead Wire |
| 15 | N/A | Crimp Connector |
| 16 | N/A | Cord Reel Spring |
| 17 | P-11393 | Brake Lever Assembly |
| 18 | P-11381 | Lead Wire Assembly |
| 19 | P-11394 | Motor Support |
| 20 | P-10670 | Noise Suppressor |
| 21 | P-11395 | Bulb Socket |
| 22 | P-111574 | Bulb |
| 23 | P-11396 | Window |
| 24 | P-111588 | Wheel Shaft |
| 25 | P-6115 | Washer |
| 26 | P-11318 | Wheel |

| Index | Part No. | Description |
|-------|----------|----------------------------|
| 27 | P-74009 | Wheel Stopper |
| 28 | P-6140 | Screw |
| 29 | P-111556 | Connector Pipe |
| 30 | P-11397 | Plastic Holder |
| 31 | P-11398 | Secondary Filter |
| 32 | N/A | Dust Compartment Packing |
| 33 | P-00104 | Wire Tie |
| 34 | P-11399 | Handle Assembly |
| 35 | P-11400 | Body Packing Right |
| 36 | P-11411 | Tool Caddy |
| 37 | P-11412 | Cord Reel Cover |
| 38 | P-11413 | Cord Guide |
| 39 | P-11414 | Cord Reel Assembly |
| 40 | P-11415 | Contact Disc Assembly |
| 41 | P-11416 | Handle Screw |
| 42 | P-111372 | Exhaust Filter |
| 43 | P-11417 | Dust Bag |
| | P-115P | Paper Bag (3 pack) |
| | P-145M | Paper Bag (micron, 6 pack) |
| 44 | P-11418 | Cover |
| 45 | P-11419 | Hose Assembly |
| 46 | P-10512 | Packing |
| 47 | P-6069 | Crevice Tool |
| 48 | P-111394 | Extension Wand |
| 49 | P-111300 | Extension Wand w/tabs |
| 50 | P-11640 | Air Turbine |
| 51 | P-6088 | Dusting Brush |

NOZZLE HOUSING

| Index | Part No. | Description |
|-------|----------|-----------------------|
| 1 | P-11420 | Nozzle Housing |
| 2 | P-683 | Screw |
| 3 | P-11421 | Furniture Guard |
| 4 | P-11371 | Agitator |
| 5 | P-11422 | Lower Plate (10 pack) |
| 6 | P-11423 | Latch |
| 7 | P-111641 | Belt Guard |
| 8 | P-11369 | Belt |
| 9 | P-4104 | Screw |
| 10 | P-000095 | Frame |
| 11 | P-6140 | Screw |
| 12 | P-513 | Pedal Shift |
| 13 | P-9857 | Pedal Spring |
| 14 | P-11424 | Pedal |
| 15 | P-11425 | Nozzle Hose |
| 16 | P-11426 | Upper Body |
| 17 | P-11427 | Upper Body Cap |
| 18 | P-6140 | Screw (10 pack) |
| 19 | P-11428 | Nozzle Roller Cam |
| 20 | P-10357 | Roller Shaft |
| 21 | P-9888 | Wheel |
| 22 | P-11429 | Floor Nozzle Spring |

