




Handle, Bag Cover & Dust Bag





- 1..... P-6800Screw, upper cord hook
- 2..... P-000633Cord Hook, upper
- 3..... P-10593Handle, upper
- 4..... P-10594Bag Support
- 5..... P-10595Cover, top bag retainer
- 6..... P-53701Bag Retainer, top
- 7..... P-10596Bag Cover
- 8..... P-MCV10P.....Paper Bag, U9, each
- 9..... P-6140Screw, lower cord hook
- 10..... P-10597Cord Hook, lower
- 11..... P-10598Handle, lower
- 12..... P-65007Bag Retainer, bottom



- 1..... P-10568 Nozzle Housing
- 2..... P-10811 Window
- 3..... P-2500 Shaft, plastic
- 4..... P-000274 Furniture Guard
- 5..... P-81 Packing, nozzle
- 6..... P-000095 Frame
- 7..... P-000010 Spring, pedal
- 8..... P-4720 Pedal
- 9..... P-6140 Screw, frame
- 10..... P-V270B Belt, UB8, 2 pk
- 11..... P-10370 Lower Plate Assy
- 12..... P-10371 Lower Plate
- 13..... P-9826 Warning label
- 14..... P-1124 Belt Cover, rear
- 15..... P-9846 Stop Latch Spring
- 16..... P-2751 Latch
- 17..... P-00051 Pedal Shaft
- 18..... P-7411 Spacer
- 19..... P-10373 Packing, lower plate front
- 20..... P-10812 Screw, spacer, 10pk
- 21..... P-83 Screw, nozzle, 10pk
- 22..... P-8220 Felt Packing
- 23..... P-392 Packing, lower plate sides
- 24..... P-742 Packing, lower plate back



- | | | |
|--|---|---|
| 1..... P-10814Dust Compartment Unit | 17..... P-145MPaper Bag, U6, micron, 3pk | 33..... P-10537Handle |
| 2..... P-10451On/Off Switch | 18..... P-000625Suction Inlet | 34..... P-10816Lead Wire Assy |
| 3.....Power Cord | 19..... P-10382Cover, suction inlet | 35..... P-10833Dust Cover |
| 4..... P-000623Wire Connector | 20..... P-6140Screw, suction inlet | 36..... P-10387Hose |
| 5..... P-660106Packing, dust container | 21..... P-10815Motor Case | 37..... P-2420Hose Supporter |
| 6..... P-10452Switch Cover | 22..... P-201Packing, rear cover | 38..... P-00104Wire Tie, 10pk |
| 7..... P-73006Packing, switch cover | 23..... P-10825Packing, motor case | 39..... P-000057Protector |
| 8..... P-6140Screw, switch cover, 10pk | 24..... P-8172Screw, motor case | 40..... P-10388Protector Spring, yellow |
| 9..... P-7301Handle Screw | 25..... P-000629Motor Assy | 41..... P-1806Protector Supporter |
| 10..... P-2117Nut, handle screw | 26..... P-10384Cover Cap | 42..... P-6806Protector Case |
| 11..... P-3200Filter Supporter | 27..... P-9912Screw, ground, 10pk | 43..... P-10389Rubber Protector |
| 12..... P-375Secondary Filter | 28..... P-10670Noise Suppressor | 44..... P-10390Flat Washer, round |
| P-9994Secondary Filter, HEPA | 29..... P-10338Motor Support, rear | 45..... P-10391Cord Retainer |
| 13..... P-10441Wheel | 30..... P-0293Motor Support Rubber, front | 46..... P-6106Packing, insulator |
| 14..... P-16005Shaft, wheel | 31..... P-10385Wire Cord | 47..... P-93033Plastic Cover, motor |
| 15..... P-74009Stopper, wheel | 32..... P-000623Wire Connector | |
| 16..... P-6115Washer, wheel, 10pk | | |



LOOK TO
THE LEADER WHEN YOU'RE
LOOKING FOR GENUINE
PANASONIC
REPAIR PARTS... HESCO!