



## Nozzle Housing



- 1..... P-10806 ..... Nozzle housing
- 2..... P-10807 ..... Lower Plate Assembly
- 3..... P-10808 ..... Lower Plate
- 4..... P-9766 ..... Body, lower plate
- 5..... P-6140 ..... Screw (body, lower plate)
- 6..... P-10394 ..... Packing, lower plate
- 7..... P-43 ..... Belt cover
- 8..... P-683 ..... Screw, Nozzle
- 9..... P-2444 ..... Latch
- 10..... P-2500 ..... Plastic shaft
- 11..... P-10456 ..... Window cover
- 12..... P-58 ..... Pedal spring
- 13..... P-9846 ..... Stop latch spring
- 14..... P-V270B ..... Belt
- 15..... P-10832 ..... Slider support
- 16..... P-10527 ..... Sliding knob
- 17..... P-10528 ..... Height adjustment cab
- 18..... P-9888 ..... Wheel
- 19..... P-10357 ..... Shaft (wheel)
- 20..... P-6140 ..... Screw (slider support, pedal spring)
- 21..... P-78 ..... Plastic holder
- 22..... P-10304 ..... Nozzle hose


### Agitator Assembly

- 1..... P-10809 .....Agitator Unit
- 2..... P-9906 .....End Cap
- 3..... P-10810 .....Brush Unit



### Motor Fan Assembly

- 1..... P-00067 .....Fan case
- 2..... P-00068 .....Nut
- 3..... P-00621 .....Washer (A)
- 4..... P-000152 .....Fan
- 5..... P-6206 .....Washer (B)
- 6..... P-10329 .....Spacer
- 7..... P-10393 .....Brush assembly
- 8..... P-0036 .....Bracket
- 9..... P-0037 .....Screws



### Body, Motor Housing, and Motor

- 1..... P-10803 .....Dust compartment unit
- 2..... P-10451 .....On/Off switch
- 3..... P-10804 .....Power cord
- 4..... P-000623 .....Wire connector
- 5..... P-660106 .....Packing (dust container)
- 6..... P-10452 .....Switch cover
- 7..... P-73006 .....Packing (switch cover)
- 8..... P-6140 .....Screw (switch cover)
- 9..... P-7301 .....Handle screw
- 10..... P-2117 .....Nut (handle screw)
- 11..... P-3200 .....Filter supporter
- 12..... P-375 .....Secondary filter
- ..... P-9994 .....Secondary Filter, HEPA
- 13..... P-10441 .....Wheel
- 14..... P-16005 .....Shaft (wheel)
- 15..... P-74009 .....Stopper (wheel)
- 16..... P-6115 .....Washer (wheel)
- 17..... P-145M .....Dust bag (type U6)
- 18..... P-10449 .....Screw (hose holder)
- 19..... P-10382 .....Cover (suction inlet)
- 20..... P-6140 .....Screw (suction inlet)
- 21..... P-11197 .....Motor case
- 22..... P-201 .....Packing (rear cover)
- 23..... P-9899 .....Packing (motor case)
- 24..... P-8172 .....Screw (motor case)
- 25..... P-10533 .....Fan motor unit
- 26..... P-10384 .....Cover cap
- 27..... P-9912 .....Screw, ground
- 28..... P-10670 .....Noise suppressor
- 29..... P-10338 .....Motor support (rear)
- 30..... P-0293 .....Motor support rubber (front)
- 31..... P-10385 .....Wire cord
- 32..... P-000623 .....Wire connector
- 33..... P-10537 .....Handle assembly
- 34..... P-10816 .....Lead wire assembly
- 35..... P-10833 .....Dust cover
- 36..... P-8946 .....Hose
- 37..... P-00104 .....Plastic cover (motor)
- 38..... P-10779 .....Wire tie
- 39..... P-000057 .....Protector
- 40..... P-692 .....Protector spring (blue)
- 41..... P-1806 .....Protector supporter
- 42..... P-6806 .....Protector case
- 43..... P-10389 .....Rubber protector
- 44..... P-10390 .....Flat washer, round
- 45..... P-10391 .....Cord retainer
- 46..... P-6106 .....Packing (insulator)
- 47..... P-10340 .....Hose hook
- 48..... P-10463 .....Hose adapter
- 49..... P-10805 .....Crevice tool
- 50..... P-6088 .....Dusting brush
- 51..... P-10781 .....Extension wand
- 52..... P-9837 .....Hose holder

### Body, Motor Housing, and Motor

