


Models: MC-V5258


## Nozzle Housing



- 1 ..... P-111440 ..... Nozzle housing
- 2 ..... P-2125 ..... Window
- 3 ..... P-10819 ..... Shaft, plastic
- 4 ..... P-000274 ..... Furniture guard
- 5 ..... P-81 ..... Packing, nozzle
- 6 ..... P-000095 ..... Frame
- 7 ..... P-111427 ..... Spring, pedal
- 8 ..... P-4720 ..... Pedal
- 9 ..... P-000132 ..... Screw, frame
- 10 ... P-00181 ..... Belt
- 11 ... P-8939 ..... Lower plate assembly
- 12 ... P-8942 ..... Lower plate
- 13 ... P-9826 ..... Warning label
- 14 ... P-1124 ..... Belt cover, rear
- 15 ... P-9846 ..... Stop latch spring
- 16 ... P-2751 ..... Latch
- 17 ... P-9367 ..... Bulb socket
- 18 ... P-00051 ..... Pedal shaft
- 19 ... P-7411 ..... Spacer
- 21 ... P-10812 ..... Screw, spacer
- 22 ... P-10109 ..... Reflector
- 23 ... P-683 ..... Screw, nozzle
- 24 ... P-7550 ..... Bulb
- 25 ... P-5045 ..... Spring, washer
- 26 ... P-8220 ..... Agitator holder
- 27 ... P-4104 ..... Screw, bulb socket
- 28 ... P-587 ..... Washer
- 29 ... P-392 ..... Packing, lower plate right
- 30 ... P-742 ..... Packing, lower plate back

Models: MC-V5258

## Motor Housing, Motor, Handle, and Body




Models: MC-V5258

## Motor Housing, Motor, Handle, and Body

1 ... P-111520 ..... Dust compartment	20 ... P-000625 ..... Suction inlet	39 ... P-3820 ..... Wire cord
2 ... P-8913 ..... On/Off switch	21 ... P-111502 ..... Cover, suction inlet	40 ... P-000623 ..... Wire connector
3 ... P-0698 ..... Cord stopper	22 ... P-6140 ..... Screw, suction inlet	41 ... P-111522 ..... Handle
4 ... P-6140 ..... Screw, cord stopper	23 ... P-111521 ..... Motor case	42 ... P-000243 ..... Upper cord storage hook
5 ... P-10802 ..... Power cord	24 ... P-201 ..... Packing, rear cover	43 ... P-111302 ..... Cord storage base
6 ... P-000623 ..... Wire connector	25 ... P-1906 ..... Packing, motor case	44 ... P-7670 ..... Spring, cord hook
7 ... P-660106 ..... Packing, dust container	26 ... P-8172 ..... Screw, motor case	45 ... P-587 ..... Washer, cord storage hook
8 ... P-301606 ..... Switch cover	27 ... P-10688 ..... Lead wire, motor thermal protector	46 ... P-111432 ..... Lower cord storage hook
9 ... P-10428 ..... Packing, switch cover	28 ... P-98109 ..... Body, indicator	47 ... P-43096 ..... Screw, cord storage hook
10 ... P-6140 ..... Screw, switch cover	29 ... P-000147 ..... Cap, indicator	48 ... P-111613 ..... Dust cover
11 ... P-7301 ..... Handle screw	30 ... P-4104 ..... Screw, indicator	49 ... P-8917 ..... Hose
12 ... P-2117 ..... Nut, handle screw	31 ... P-10343 ..... Fan motor unit	50 ... P-2420 ..... Hose supporter
13 ... P-3200 ..... Filter supporter	32 ... P-8182 ..... Carbon brush	51 ... P-000149 ..... Lead, indicator
14 ... P-9994 ..... Secondary filter, HEPA	33 ... P-10712 ..... Lead wire, motor	52 ... P-10400 ..... Spring, indicator
15 ... P-0114 ..... Wheel	34 ... P-9823 ..... Screw, brush (not illustrated)	53 ... P-9300 ..... Packing, indicator
16 ... P-10968 ..... Shaft, wheel	35 ... P-8184 ..... Ring spacer	54 ... P-00104 ..... Wire tie
17 ... P-74009 ..... Stopper, wheel	36 ... P-10670 ..... Noise suppressor	55 ... P-6106 ..... Packing, insulator
18 ... P-6115 ..... Washer	37 ... P-0293 ..... Motor support, front	56 ... P-10697 ..... Packing, right
19 ... P-111387 ..... Dust bag, type U6	38 ... P-10338 ..... Motor support rubber, rear	57 ... P-10698 ..... Packing, left

## Agitator Assembly



1 ... P-111511 ..... Agitator assembly
2 ... P-111512 ..... Brush, 3 pcs.
3 ... P-111614 ..... Agitator pulley
4 ... P-111513 ..... Agitator holder
5 ... P-111514 ..... Filter
6 ... P-111516 ..... Brush support, right
7 ... P-111517 ..... Brush support, left
8 ... P-111518 ..... Agitator shaft
9 ... P-111465 ..... Ring clip
10 ... P-111519 ..... Agitator