


Models: MC-V5267

Nozzle Housing


- 1 ... P-8938 Nozzle housing
- 2 ... P-2125 Window
- 3 ... P-10819 Shaft, plastic
- 4 ... P-000274 Furniture guard
- 5 ... P-81 Packing, nozzle
- 6 ... P-0100095 Frame
- 7 ... P-111427 Spring, pedal
- 8 ... P-7549 Nozzle housing
- 9 ... P-4720 Pedal
- 10 ... P-6140 Screw, frame
- 11 ... P-00181 Belt
- 12 ... P-8939 Lower plate assembly
- 13 ... P-8942 Lower plate
- 14 ... P-1124 Belt cover, rear
- 15 ... P-9846 Stop latch spring
- 16 ... P-2751 Latch
- 17 ... P-9367 Bulb socket
- 18 ... P-00051 Pedal shaft
- 19 ... P-7411G Spacer
- 20 ... P-111468 Packing, lower plate, front
- 21 ... P-10812 Screw, spacer
- 22 ... P-10109 Reflector
- 23 ... P-683 Screw, nozzle
- 24 ... P-7550 Bulb
- 25 ... P-5045 Spring, washer
- 26 ... P-8220 Agitator holder
- 27 ... P-4104 Screw, bulb socket
- 28 ... P-587 Washer
- 29 ... P-392 Packing, lower plate, right
- 30 ... P-742 Packing, lower plate, back
- 31 ... P-2420 Hose supporter
- 32 ... P-9826 Warning label



Models: MC-V5267

Agitator Assembly

- 1 P-5491 Agitator assembly
- 2 P-5492 Brush, 4 pcs.
- 3 P-5918 Agitator pulley
- 4 P-111428 Agitator holder
- 5 P-10376 Filter
- 6 P-9709 Brush support, right
- 7 P-9708 Brush support, left
- 8 P-10858 Agitator shaft
- 9 P-4003 E-clip



Motor Housing, Motor, Handle, and Body

- | | |
|---|--|
| 1 P-111437 Dust compartment unit | 31 ... P-111417 Protector case, motor |
| 2 P-111438 Wand holder | 32 ... P-111416 Protector supporter, motor |
| 3 P-6140 Screw, wand holder | 33 ... P-10877 Fan motor unit |
| 4 P-8913 On-off switch | 34 ... P-8182 Carbon brush |
| 5 P-0698 Cord stopper | 35 ... P-9823 Screw, brush (not illustrated) |
| 6 P-6140 Screw, cord stopper | 36 ... P-10670 Noise suppressor |
| 7 P-10935 power cord | 37 ... P-0293 Motor support, front |
| 8 P-000623 Wire connector | 38 ... P-10338 Motor support rubber, rear |
| 9 P-660106 Packing, dust container | 39 ... P-3820 Wire cord |
| 10 ... P-30606 Switch cover | 40 ... P-00623 Wire connector |
| 11 ... P-73006 Packing, switch cover | 41 ... P-9835 Handle |
| 12 ... P-6140 Screw, switch cover | 42 ... P-000243 Upper cord storage hook |
| 13 ... P-7301 Handle screw | 43 ... P-111469 Hose holder |
| 14 ... P-2117 Nut, handle screw | 44 ... P-7670 Spring, cord hook |
| 15 ... P-3200 Filter supporter | 45 ... P-587 Washer, cord storage hook |
| 16 ... P-9829 Secondary filter, electrostatic | 46 ... P-000218 Lower cord storage hook |
| 17 ... P-0114 Wheel | 47 ... P-43096 Screw, cord storage hook |
| 18 ... P-10968 Shat, wheel | 48 ... P-111470 Dust cover |
| 19 ... P-74009 Stopper, wheel | 49 ... P-8946 hose |
| 20 ... P-6115 Washer | 50 ... P-6088 Dusting brush |
| 21 ... P-111387 Dust bag, type U6 | 51 ... P-6069 Crevice tool |
| 22 ... P-10340 Hose ring | 52 ... P-60104 Wand, extension |
| 23 ... P-8972 Cover, suction inlet | 53 ... P-8180 Wand, with tabs |
| 24 ... P-6140 Screw, suction inlet | 54 ... P-00104 Wire tie |
| 25 ... P-10876 Motor case | 55 ... P-6106 Packing, insulator |
| 26 ... P-10916 packing, rear cover | 56 ... P-3990 Packing, right |
| 27 ... P-10825 Packing, motor case | 57 ... P-5860 Packing, left |
| 28 ... P-8172 Screw, motor case | 58 ... P-111429 Lead assembly |
| 29 ... P-6096 Protector, motor | 59 ... P-10712 Lead wire, motor |
| 30 ... P-10415 Protector spring, blue | |

