


Models: MC-V5268


## Nozzle Housing



- 1 ..... P-111523 ..... Nozzle housing
- 2 ..... P-2125 ..... Window
- 3 ..... P-10819 ..... Shaft, plastic
- 4 ..... P-000274 ..... Furniture guard
- 5 ..... P-81 ..... Packing, nozzle
- 6 ..... P-000095 ..... Frame
- 7 ..... P-111427 ..... Spring, pedal
- 8 ..... P-10304 ..... Nozzle hose
- 9 ..... P-4720 ..... Pedal
- 10 ... P-6140 ..... Screw, frame
- 11 ... P-00181 ..... Belt
- 12 ... P-8939 ..... Lower plate assembly
- 13 ... P-8942 ..... Lower plate
- 14 ... P-1124 ..... Belt cover, rear
- 15 ... P-9846 ..... Stop latch spring
- 16 ... P-2751 ..... Latch
- 17 ... P-9367 ..... Bulb socket
- 18 ... P-00051 ..... Pedal shaft
- 19 ... P-7411 ..... Spacer
- 21 ... P-8172 ..... Screw, spacer
- 22 ... P-10109 ..... Reflector
- 23 ... P-683 ..... Screw, nozzle
- 24 ... P-7550 ..... Bulb
- 25 ... P-5045 ..... Spring, washer
- 26 ... P-8220 ..... Agitator holder
- 27 ... P-4104 ..... Screw, bulb socket
- 28 ... P-587 ..... Washer
- 29 ... P-392 ..... Packing, lower plate right
- 30 ... P-742 ..... Packing, lower plate back
- 31 ... P-2420 ..... Hose supporter
- 32 ... P-9826 ..... Warning label
- 33 ... P-10373 ..... Packing, lower plate front

Models: MC-V5268

## Motor Housing, Motor, Handle, and Body




Models: MC-V5268

## Motor Housing, Motor, Handle, and Body

1 ... P-111524 .....	Dust compartment	22 ... P-10340 .....	Hose hook	42 ... P-111432 .....	Lower cord storage hook
2 ... P-111461 .....	Wand holder	23 ... P-111450 .....	Cover, suction inlet	43 ... P-43096 .....	Screw, cord storage hook
3 ... P-6140 .....	Screw, wand holder	24 ... P-6140 .....	Screw, suction inlet	44 ... P-111613 .....	Dust cover
4 ... P-8913 .....	On/Off switch	25 ... P-111521 .....	Motor case	45 ... P-8946 .....	Hose
5 ... P-0698 .....	Cord stopper	26 ... P-201 .....	Packing, rear cover	46 ... P-6088 .....	Dusting brush
6 ... P-6140 .....	Screw, cord stopper	27 ... P-1906 .....	Packing, motor case	47 ... P-6069 .....	Crevice tool
7 ... P-10802 .....	Power cord	28 ... P-8172 .....	Screw, motor case	48 ... P-8180 .....	Wand, with tabs
8 ... P-000623 .....	Wire connector	29 ... P-10343 .....	Fan motor unit	49 ... P-60104 .....	Wand, extension
9 ... P-660106 .....	Packing, dust container	30 ... P-8182 .....	Carbon brush	50 ... P-6106 .....	Packing, insulator
10 ... P-30606 .....	Switch cover	31 ... P-9823 .....	Screw, brush (not illustrated)	51 ... P-10697 .....	Packing, right
11 ... P-6037 .....	Packing, switch cover	32 ... P-10670 .....	Noise suppressor	52 ... P-10698 .....	Packing, left
12 ... P-6140 .....	Screw, switch cover	33 ... P-0293 .....	Motor support, front	53 ... P-000149 .....	Lead, indicator
13 ... P-7301 .....	Handle screw	34 ... P-10338 .....	Motor support rubber, rear	54 ... P-10400 .....	Spring, indicator
14 ... P-2117 .....	Nut, handle screw	35 ... P-3820 .....	Wire cord	55 ... P-98109 .....	Body, indicator
15 ... P-3200 .....	Filter supporter	36 ... P-000623 .....	Wire connector	56 ... P-111525 .....	Cap, indicator
16 ... P-9994 .....	Secondary filter, HEPA	37 ... P-9835 .....	Handle	57 ... P-9300 .....	Packing, indicator
17 ... P-0114 .....	Wheel	38 ... P-000243 .....	Upper cord storage hook	58 ... P-4104 .....	Screw, indicator
18 ... P-10968 .....	Shaft, wheel	39 ... P-111469 .....	Hose holder	59 ... P-8184 .....	Ring spacer
19 ... P-74009 .....	Stopper, wheel	40 ... P-7670 .....	Spring, cord hook	60 ... P-10712 .....	Lead wire, motor
20 ... P-6115 .....	Washer	41 ... P-587 .....	Washer, cord storage hook	61 ... P-10688 .....	Thermal protector unit

## Agitator Assembly



1 ... P-111511 .....	Agitator assembly
2 ... P-111512 .....	Brush, 3 pcs.
3 ... P-111614 .....	Agitator pulley
4 ... P-111513 .....	Agitator holder
5 ... P-111514 .....	Filter
6 ... P-111517 .....	Brush support, left
7 ... P-111516 .....	Brush support, right
8 ... P-111518 .....	Agitator shaft
9 ... P-111465 .....	Ring clip
10 ... P-111519 .....	Agitator