


Models: MC-V5745

Body




Index	Part No.	Description
1	P-11608	Dust Compartment Unit
2	P-10508	Lead Wire
3	P-0698	Cord Stopper
4	P-6140	Screw (Cord Stopper)
5	P-97062	Power cord
6	P-000623	Wire Connector
7	P-10309	Packing (Dust Compartment)
8	P-10312	Switch Cover
9	P-6140	Screw (Switch Cover)
10	P-6069	Crevice Tool
11	P-10512	Packing (Suction Inlet)
12	P-4410	Lead Wire
13	P-111581	Front Cover
14	P-10314	Secondary Filter (Foam)
15	P-0114	Wheel
16	P-111588	Shaft (Wheel)
17	P-74009	Stopper (Wheel)
18	P-6115	Washer (Wheel)
19	P-115P	Dust Bag (Electrostatic)
20	P-10315	Protector Cover
21	P-6096	Protector

Index	Part No.	Description
22	P-10316	Protector Spring (Red)
23	P-6140	Screw (Front Cover)
24	P-10602	On-Off Switch
25	P-9907	Handle Screw
26	P-10317	Packing (Right)
27	P-5860	Packing (Left)
28	P-11280	Dust Cover
29	P-3820	Wire Cord
30	P-11281	Exhaust Filter (HEPA)
31	P-1847	Hose
32	P-111726	Dusting Brush
33	P-60104	Extension Wand (Without Tabs)
34	P-111610	Handle
35	P-111584	Handle Cap
36	P-7035	Upper Cord Storage Hook
37	P-8180	Wand (With Tabs)
38	P-9873	Hose Ring
39	P-111583	Handle Assembly
40	P-111611	Wand Holder
41	P-6140	Screw (Wand Holder)

Models: MC-V5745


Nozzle Housing



Index	Part No.	Description
1	P-11283	Nozzle Housing
2	P-9854	Window
3	P-10819	Shaft (Plastic)
4	P-10351	Furniture Guard
5	P-11282	Light Cover
6	P-8172	Screw (Light Cover)
7	P-10733	Capet/Bare Floor Release Assembly
8	P-9857	Spring (Pedal)
9	P-513	Shaft (Pedal)
10	P-02181	Screw (Pedal/Frame Assembly)
11	P-4720	Pedal (Black)
12	P-111607	Foot Pedal Cover
13	P-V270B	Belt
14	P-9764	Lower Plate Assembly
15	P-9765	Lower Plate
16	P-10394	Packing (Lower Plate)

Index	Part No.	Description
17	P-9861	Belt Cover
18	P-6800	Screw (Slider Support)
19	P-10304	Nozzle Hose
20	P-10353	Slider Support
21	P-6140	Screw (Slider Support)
22	P-9367	Socket (Bulb)
23	P-7550	Bulb
24	P-9766	Body (Lower Plate)
25	P-6800	Screw (Lower Plate)
26	P-98103	Packing (Nozzle)
27	P-6140	Screw (Lower Plate)
28	P-02184	Spring (Shifter Return)
29	P-9888	Wheel
30	P-10357	Shaft (Wheel)
31	P-111553	Agitator Unit

Motor Case and Motor



Index	Part No.	Description
1	P-0293	Motor Support, Rubber (Front)
2	P-10846	Fan Motor Unit
3	P-8182	Carbon Brush Assembly
4	P-9823	Screw (Carbon Brush Assembly)
5	P-8184	Ring Spacer
6	P-8183	Motor Support, Rubber (Rear)
7	P-9931	Noise Suppressor
8	P-000623	Wire Connector
9	P-11092	Packing (Rear Cover)
10	P-111585	Motor Case
11	P-6140	Screw (Motor Case)
12	P-11276	Fuse Assembly
13	P-10712	Lead Wire
14	P-7805	Plastic Holder