


Models: MC-V7315, MC-V7325, MC-V7335, MC-V7355, MC-V7337, MC-V7375, MC-V7395

## Nozzle Housing




- 1..... P-5966..... Nozzle Housing, V7315
- 1..... P-8170..... Nozzle Housing, V7325
- 1..... P-9916..... Nozzle Housing, V7335
- 1..... P-9898..... Nozzle Housing, V7337
- 1..... P-9917..... Nozzle Housing, V7355
- 1..... P-11025..... Nozzle Housing, V7375
- 1..... P-11026..... Nozzle Housing, V7395
- 2..... P-9854..... Window
- 3..... P-2500..... Shaft, plastic
- 4..... P-9855..... Furniture Guard
- 5..... P-9856..... Light Cover, V7315
- 5..... P-8171..... Light Cover, V7325
- 5..... P-9918..... Light Cover, V7335, V7375
- 5..... P-98100..... Light Cover, V7337
- 5..... P-9879..... Light Cover, V7355
- 5..... P-11035..... Light Cover, V7395
- 6..... P-8172..... Screw, light cover, V7325
- 6..... P-42092..... Screw, light cover, V7337
- 7..... P-9878..... Frame
- 7..... P-000095..... Frame, V7315, V7325
- 8..... P-9857..... Spring, pedal
- 9..... P-513..... Shaft, pedal
- 10..... P-4106..... Screw, pedal/frame
- 11..... P-4720..... Pedal, black
- 12..... P-9880..... Cover, foot pedal
- 12..... P-10207..... Cover, foot pedal, V7375, V7395
- 13..... P-V270B..... Belt, type UB8, 2 pack
- 14..... P-9858..... Bottom Plate Assy, V7315
- 14..... P-8947..... Bottom Plate Assy, V7325
- 14..... P-9881..... Bottom Plate Assy, V7335, V7355
- 14..... P-98101..... Bottom Plate Assy, V7337
- 14..... P-9764..... Bottom Plate Assy, V7375, V7395
- 15..... P-2859..... Bottom Plate, V7315
- 15..... P-5893..... Bottom Plate, V7325
- 15..... P-5964..... Bottom Plate, V7335, V7355
- 15..... P-98102..... Bottom Plate, V7337
- 15..... P-9765..... Bottom Plate, V7375, V7395
- 16..... P-6140..... Screw, pedal shaft
- 17..... P-9861..... Belt Cover
- 18..... P-6800..... Screw, slider support
- 19..... P-9862..... Nozzle Hose, short
- 19..... P-00121..... Nozzle Pipe, V7337
- 20..... P-9863..... Slider Support
- 21..... P-6140..... Screw, slider support
- 22..... P-9367..... Socket, bulb
- 23..... P-2810..... Bulb
- 24..... P-9883..... Foot Gear Pedal
- 25..... P-9884..... Shoulder Screw
- 26..... P-9885..... Nut/Lock Washer
- 27..... P-9886..... Spring, foot gear pedal

- 28..... P-9887..... Spring, pedal assembly
- 29..... P-9888..... Wheel
- 30..... P-9889..... Roller Shaft
- 31..... P-10367..... Belt Gear
- 32..... P-9891..... Retaining Ring
- 33..... P-98103..... Packing, nozzle
- 33..... P-9919..... Packing, nozzle, V7335, V7355
- 34..... P-98104..... Screw, bottom plate, V7337
- 35..... P-2444..... Latch, bottom plate, V7337
- 36..... P-9846..... Spring, stop latch
- 37..... P-683..... Screw

- P-4104..... Screw, handle release, V7315, V7325
- P-9766..... Body Lower Plate, V7325


## Body Assembly



Models: MC-V7315, MC-V7325, MC-V7335, MC-V7355, MC-V7337, MC-V7375, MC-V7395

- |   |  |   |
|---|--|---|
| 1.....P-9865..... Dust Compartment, V7315           | 13....P-9893..... Filter Supporter                   | 28....P-9933..... Dust Cover, V7355   |
| 1.....P-8173..... Dust Compartment, V7325           | 14....P-7023..... Secondary Filter, foam             | 28....P-11030..... Dust Cover, V7375  |
| 1.....P-9924..... Dust Compartment, V7335, V7355    | 15....P-0114..... Wheel                              | 28....P-11031..... Dust Cover, V7395  |
| 1.....P-98107..... Dust Compartment, V7337          | 16....P-16005..... Shaft, wheel                      | 29....P-3820..... Wire Cord   |
| 1.....P-11027..... Dust Compartment, V7375, V7395   | 17....P-74009..... Stopper, wheel                    | 30....P-3099..... Exhaust Filter, electrostatic, V7315, V7335, V7337, V7355 |
| 2.....P-9869..... Packing, dust cover               | 18....P-6115..... Washer                             | 30....P-8176..... Exhaust Filter, HEPA, V7325, V7375, V7395                 |
| 3.....N/A..... Cord Stopper                         | 19....P-115P..... Paper Bag, type U3, 3 pack         | 31....P-5472..... PC Assembly   |
| 3.....P-0698..... Cord Stopper, V7325, V7375, V7395 | 20....P-9928..... Sensor Sensitivity Knob            | 32....P-9934..... Ornamental Plate  |
| 4.....P-6140..... Screw, cord stopper               | 21....P-7082..... Cover, bag supporter               | 33....P-9935..... LED Lens  |
| 5.....P-7906..... Power Cord                        | 22....P-6140..... Screw, bag supporter               | 34....P-6800..... Screw, on/off switch                                      |
| 6.....P-000623... Wire Connector                    | 23....P-5470..... Bag Supporter Assembly             | 35....P-00104..... Wire Tie   |
| 7.....P-9866..... Packing, dust container           | 23....P-10358..... Bag Supporter, V7315, V7337       | P-98109..... Indicator Body, V7337  |
| 7.....P-9869..... Packing, dust container, V7315    | 23....P-8175..... Bag Supporter, V7325               | P-9300..... Indicator Packing, V7337  |
| 8.....P-9867..... Switch Cover, V7315, V7337        | 24....P-10602..... On/Off Switch, V7315, V7325       | P-000148... Indicator Spring, V7337   |
| 8.....P-8174..... Switch Cover, V7325               | 24....P-0696..... On/Off Switch, V7335, V7337        | P-000149... Indicator Lead, V7337   |
| 8.....P-9925..... Switch Cover, V7335, V7375        | 24....P-9929..... On/Off Switch, V7355, V7395        | P-000147... Indicator Cap, V7337  |
| 8.....P-9920..... Switch Cover, V7355               | 24....P-0696..... On/Off Switch, V7375               | P-4104..... Indicator Screw, V7337  |
| 8.....P-11029..... Switch Cover, V7395              | 25....P-000024... Switch Lever                       |   |
| 9.....P-9927..... Partition Board                   | 25....P-0701..... Switch Lever, V7325, V7375, V7395  |   |
| 10....P-6140..... Screw, switch cover               | 26....P-3990..... Packing, right                     |   |
| 11....P-3879..... Screw, optic cells                | 27....P-4160..... Packing, left                      |   |
| 12....P-9892..... Lead Wire                         | 27....P-5860..... Packing, left, V7325, V7375, V7395 |   |
| 12....P-4410..... Lead Wire, V7315, V7355           | 28....P-9868..... Dust Cover, V7315                  |   |
| 12....N/A..... Lead Wire, V7395                     | 28....P-8948..... Dust Cover, V7325                  |   |
|   | 28....P-9932..... Dust Cover, V7335                  |   |
|   | 28....P-98108..... Dust Cover, V7337                 |   |


## Motor & Motor Case Assembly



- |  |  |  |
|--|--|--|
| 1.....P-0293..... Motor Support Rubber, front            | 6.....P-8183..... Motor Support Rubber, rear, V7325      | 13....P-9876..... Motor Support Foam                 |
| 2.....P-2908..... Motor Assy, V7315                      | 7.....P-9931..... Noise Suppressor                       | 14....P-0410..... Cooling Guide                      |
| 2.....P-8181..... Motor Assy, V7325                      | 8.....P-000623... Wire Nut                               | 15....P-4160..... Body Packing, motor case           |
| 2.....P-9905..... Motor Assy, V7335, V7355               | 9.....P-9874..... Packing, rear cover                    | 16....P-9877..... Motor Support Rubber Insert, front |
| 2.....P-9905..... Motor Assy, V7337                      | 10....P-9875..... Motor Case, V7315                      | N/A..... Flange, V7335, V7337, V7355, V7375, V7395   |
| 2.....P-11033... Motor Assy, V7375, V7395                | 10....P-8949..... Motor Case, V7325                      | P-9912..... Screw, flange,                           |
| 3.....P-270091... Carbon Brush Assy                      | 10....P-9939..... Motor Case, V7335, V7375               | P-8184..... Ring Spacer, V7325, V7375, V7395         |
| 3.....P-8182..... Carbon Brush Assy, V7325, V7375, V7395 | 10....P-98113... Motor Case, V7337                       | N/A..... Lead Wire, V7325, V7375, V7395              |
| P-6800..... Screw, carbon brush, V7325                   | 10....P-9944..... Motor Case, V7355                      |  |
| P-9823..... Screw, carbon brush, V7375, V7395            | 10....P-11034... Motor Case, V7395                       |  |
| 4.....P-0036..... Retainer Bracket, carbon brush         | 11....P-42092... Screw, motor case                       |  |
| 5.....P-0037..... Screw, brush bracket                   | 11....P-8172..... Screw, motor case, V7325, V7375, V7395 |  |
| 6.....P-9911..... Motor Support Rubber, rear             | 12....P-7805..... Plastic Holder                         |  |


Models: MC-V7315, MC-V7325, MC-V7335, MC-V7355, MC-V7337, MC-V7375, MC-V7395

## Handle Assembly & Rear Dust Compartment



- |   |  |  |
|---|--|--|
| 1..... P-9865 ..... Dust Compartment, V7315         | 4..... P-000048 ..... Screw, handle, V7315                       | 13.... P-6806 ..... Protector Case                   |
| 1..... N/A..... Dust Compartment, V7325             | 5..... P-8972 ..... Cover, suction inlet                         | 14.... P-7089 ..... Protector Spring                 |
| 1..... P-9924 ..... Dust Compartment, V7335, V7355  | 6..... P-0648 ..... Hose   | 15.... P-6096 ..... Protector                        |
| 1..... N/A..... Dust Compartment, V7337             | 6..... P-8179 ..... Hose, V7325                                  | 16.... P-1806 ..... Protector Supporter              |
| 1..... P-11027 ..... Dust Compartment, V7375, V7395 | 6..... P-0648 ..... Hose, V7375, V7395                           | 17.... P-9896 ..... Wand Holder, V7337               |
| 2..... P-9872 ..... Handle Assy, V7315              | 7..... P-9908 ..... Switch Knob                                  | 17.... P-7070 ..... Wand Holder, V7355, V7375, V7395 |
| 2..... P-8178 ..... Handle Assy, V7325              | 7..... P-9938 ..... Switch Knob, V7355, V7395                    | 18.... P-6140 ..... Screw, holder                    |
| 2..... P-9936 ..... Handle Assy, V7335              | 8..... P-9894 ..... Packing, suction inlet                       | 19.... P-9897 ..... Holder, dust brush               |
| 2..... P-98111 ..... Handle Assy, V7337             | 9..... P-6088 ..... Dusting Brush                                | 20.... P-9873 ..... Hose Ring                        |
| 2..... P-9937 ..... Handle Assy, V7355              | 10.... P-6620 ..... Upholstery Tool                              | 20.... P-000061 ..... Hose Ring, V7335, V7355        |
| 2..... P-9768 ..... Handle Assy, V7375              | 11.... P-6069 ..... Crevice Tool                                 | P-98112 ..... Mount, hose ring                       |
| 2..... P-11032 ..... Handle Assy, V7395             | 12.... P-9895 ..... Telescoping Wand, V7337                      | 21.... P-60104 ..... Extension Wand, no tabs         |
| 3..... P-7035 ..... Cord Hook, upper                | 12.... P-8180 ..... Extension Wand, w/ tabs, V7325, V7375, V7395 |  |
| 4..... P-9907 ..... Screw, handle                   |  |  |

## Agitator Assembly



- |   |
|---|
| 1..... P-9767..... Agitator Unit, V7325, V7375, V7395 |
| 1..... P-9864..... Agitator Unit, V7315, V7335, V7355 |
| 2..... P-7095..... End Cap                            |
| 3..... P-0030..... Washer                             |

### MC-V7337 AGITATOR

- |                                |
|--------------------------------|
| P-98105..... Brush Holder      |
| P-9906..... End Cap (2)        |
| P-98106..... Agitator Pulley   |
| P-110113 ..... Agitator Holder |
| P-110114 ..... Brush Unit      |