


PANASONIC

V-Series Uprights

Models: MC-V7348, MC-V5257



- 1 P-10834 Nozzle Housing
- 2 P-9884 Window
- 2 P-9885 Window, V5257
- 3 P-9302 Shaft, plastic
- 4 P-10351 Furniture Guard
- 5 P-8921 Light Cover
- 6 P-8172 Screw, light cover
- 7 P-10733 Carpet/Bare Floor -
Handle Release Assy
- 7 P-10914 Carpet/Bare Floor -
Handle Release Assy, V5257
- 8 P-9857 Spring, pedal
- 9 P-513 Shaft, pedal
- 10 ... P-02181 Screw, pedal/frame assy
- 11 ... P-4720 Pedal, black
- 12 ... P-10835 Foot Pedal Cover
- 13 ... P-V270B Belt, UB8, 2 pack
- 13 ... P-00181 Belt, each, V5257
- 14 ... P-10672 Bottom Plate Assy
- 15 ... P-10681 Lower Plate
- 16 ... P-10394 packing, lower plate/body

- 17 ... P-9861 Belt Cover
- 18 ... P-6800 Screw, slider support
- 19 ... P-10304 Nozzle Hose
- 20 ... P-10353 Slider Support
- 21 ... P-6140 Screw, slider support
- 22 ... P-9367 Socket, bulb
- 23 ... P-7550 Bulb


- 24 ... P-98104 Screw, metal lower plate
- 25 ... P-2444 Latch, lower plate
- 26 ... P-9846 Spring, stop latch
- 27 ... P-683 Screw, nozzle housing latch
- 28 ... P-9766 Body, lower plate
- 29 ... P-9888 Wheel
- 30 ... P-10357 Shaft, wheel
- 31 ... P-02184 Spring, shifter return
- 32 ... P-6140 Screw, body, lower plate
- 33 ... P-98103 Packing, nozzle

PHONE: 1-800-822-7467 FAX: 847-647-0534 E-MAIL: sales@hescoinc.com WEB: www.hescoinc.com

PANASONIC

V-Series Uprights


Models: MC-V7348, MC-V5257



Models: MC-V7348, MC-V5257

- | | | |
|--|---|--|
| 1 P-10836 Dust Compartment Unit | 25 .. P-10825 Packing, motor case, V5257 | 46 .. P-10781 Wand, with tabs |
| 1 P-10880 Dust Compartment Unit, V5257 | 26 .. P-6140 Screw, motor case | 46 .. P-10884 Wand, with tabs, V5257 |
| 2 P-8913 On-Off Switch | 26 .. P-8172 Screw, motor case, V5257 | 47 .. P-6106 Packing, insulator |
| 3 P-0698 Cord Stopper | 27 .. P-10405 Motor Assy | 48 .. P-10697 Packing, right |
| 4 P-6140 Screw, cord stopper | 27 .. P-10882 Motor Assy, V5257 | 48 .. P-3990 Packing, right, V5257 |
| 5 P-10802 Power Cord | 28 .. P-8182 Carbon Brush, pair | 49 .. P-10698 Packing, left |
| 6 P-000623 .. Wire Connector | 29 .. P-9823 Screw, carbon brush | 49 .. P-5860 Packing, left, V5257 |
| 7 P-660106 .. Packing, dust container | 30 .. P-10670 Noise Suppressor | 50 .. P-000149 .. Lead, indicator |
| 8 P-30606 Switch Cover | 31 .. P-0293 Motor Support, front | 51 .. P-10400 Spring, indicator |
| 9 P-73006 Packing, switch cover | 32 .. P-9911 Motor Support Rubber, rear | 51 .. P-10885 Spring, indicator, V5257 |
| 10 .. P-6140 Screw, switch cover | 33 .. P-3820 Wire Cord | 52 .. P-98109 Body, indicator |
| 11 .. P-7301 Handle Screw | 34 .. P-000623 .. Wire Nut, 10pk | 53 .. P-000147 .. Cap, indicator |
| 12 .. P-2117 Nut, handle screw | 35 .. P-9835 Handle | 54 .. P-9300 Packing, indicator |
| 13 .. P-3200 Filter Supporter | 36 .. P-9836 Upper Cord Storage Hook | 55 .. P-4104 Screw, indicator |
| 14 .. P-9994 Secondary Filter, HEPA | 36 .. P-53007 Upper Cord Storage Hook, V5257 | 56 .. P-8184 Ring Spacer |
| 14 .. P-9829 Secondary Filter, HEPA, V5257 | 37 .. P-9837 Hose Holder | 57 .. P-10712 Lead Wire |
| 15 .. P-0114 Wheel | 38 .. P-7670 Spring, cord hook | 58 .. P-10688 Thermal Protector Unit |
| 16 .. P-16005 Shaft, wheel | 39 .. P-587 Washer, cord storage hook | 58 .. P-10848 Thermal Protector Unit, V5257 |
| 17 .. P-74009 Stopper, wheel | 40 .. P-9838 Lower Cord Storage Hook | 59 .. P-60104 Extension Wand, no tabs |
| 18 .. P-6115 Washer | 40 .. P-53007 Lower Cord Storage Hook, V5257 | 60 .. P-00104 Wire Tie, 10 pk |
| 19 .. P-145M Paper Bag, U6, micro, 3pk | 41 .. P-43096 Screw, cord storage hook | 61 .. P-10649 Cooling Guide |
| 20 .. P-10340 Hose Hook | 42 .. P-10838 Dust Cover | 62 .. P-10839 Screw, flange, 10 pk |
| 21 .. P-8972 Cover, suction inlet | 42 .. P-10883 Dust Cover, V5257 | 63 .. P-9960 Flange |
| 22 .. P-6140 Screw | 43 .. P-8946 Hose | P-60104 Wand, extension, V5257 |
| 23 .. P-10837 Motor Case | 44 .. P-6088 Dusting Brush | P-10863 Wand Holder, V5257 |
| 23 .. P-10881 Motor Case, V5257 | 45 .. P-6069 Crevice Tool | P-6140 Screw, wand holder, V5257 |
| 24 .. P-201 Packing, rear | 45 .. P-10805 Crevice Tool, V5257 | |
| 24 .. P-10916 Packing, rear, V5257 | | |
| 25 .. P-1906 Packing, motor case | | |

Agitator Assembly



- | | | |
|---|------------------------------------|---------------------------------|
| 1 P-10682 Agitator Assembly | 5 P-10376 Filter | 10 .. P-8403 Brush Holder |
| 2 P-10375 Brush, 4 piece | 6 P-9709 End Cap, right | 11 .. P-10378 Spring Pin |
| 2 P-10915 Brush, 4 piece, V5257 | 7 P-9708 End Cap, left | 12 .. P-10716 Spacer |
| 3 P-10683 Agitator Pulley | 8 P-10684 Agitator Shaft | |
| 4 P-10801 Agitator Holder | 9 P-4003 E-Clip | |