


Models: 4700, 4750

For hardware items NOT listed in this schematic, refer to page 81.



- |  |  |
|--|--|
| 1.....R-041437A.....Cord & Plug Assy, 4700           | 22 .....R-040174B.....Clamp Assy                           |
| 1.....R-414376.....Cord & Plug Assy, 4750            | 23 .....R-4750408.....Handle & Wiring Duct Assy, 4700      |
| 2.....R-415700.....Rear End Bell Assy, 4700          | 23 .....R-470220.....Handle & Wire Duct Assy, 4750         |
| 2.....R-157008.....Rear End Bell Assy, 4750          | 24 .....R-470130A.....Upper Wand & Cuff Assy, 4700         |
| 3.....R-460030.....Microfresh Filter                 | 24 .....R-470130.....Upper Wand & Cuff Assy, 4750          |
| 4.....R-880304.....Strain Relief                     | 25 .....R-470250.....Lower Wand Assy, 4700                 |
| 5.....R-401062.....Rear Motor Support & Speed        | 25 .....R-702508.....Lower Wand Assy, 4750                 |
| 6.....R-350060.....Rubber Motor Support              | 26 .....R-470200.....Power Grip & Electric Hose Assy, 4700 |
| 7.....R-435210.....Motor, variable speed             | 26 .....R-475020.....Power Grip & Electric Hose Assy, 4750 |
| 8.....R-413302.....Switch                            | 27 .....R-460780.....Complete Hose Connector Assy, 4700    |
| 9.....R-411000A.....Tool Caddy, 4700                 | 27 .....R-607808.....Cmplete Hose Connector Assy, 4750     |
| 9.....R-411000A.....Tool Caddy, 4750                 | 28 .....R-470310.....Female Plug w/leads                   |
| 10.....R-041162.....Casting & Ring Assy, 4700        | 29 .....NLA.....Rear Wheel                                 |
| 10.....R-041178.....Casting & Ring Assy, 4750        | 30 .....R-988440.....Caster, swivel ball                   |
| 11.....R-041140.....Bag Assy                         | 31 .....R-411277.....Air Deflector                         |
| 12.....R-467130.....Paper Bag, 3 pack                | 32 .....R-701119.....Wheel Bracket Stamping                |
| 13.....R-040173.....Front End Bell Assy              | 33 .....R-7013146.....Grip, dark gray, 4700                |
| 14.....R-460235A.....Upper Plug Assy, 4700           | 33 .....R-701314B.....Grip, burgundy, 4750                 |
| 14.....R-4601358.....Upper Plug Assy, 4750           | 34 .....R-170000A.....Power Grip Housing Assy, 4700        |
| 15.....R-470260A.....Female Plug Housing, 4700       | 35 .....R-4750408.....Electrified Hose, 4700               |
| 15.....R-4702606.....Female Plug Housing, 4750       | 35 .....R-475040.....Electrified Hose, 4750                |
| 16.....NLA.....Dust Brush Assy, burgundy, 4750       | 36 .....R-470300A.....Pigtail, male plug, 4700             |
| 17.....NLA.....10" Floor Brush Assy, 4700            | 36 .....R-470300.....Pigtail, male plug, 4750              |
| 17.....R-435200.....10" Floor Brush Assy, 4750       | 37 .....R-966006.....Wheel Bracket                         |
| 18.....R-258801A.....Crevice Tool, magnum blue, 4700 | 38 .....R-4351500.....InsertTube                           |
| 19.....R-415582A.....6" Upholstery Tool, 4700        | 40 .....NLA.....Release Button                             |
| 19.....R-435200.....6" Upholstery Tool, 4750         | 41 .....R-435160.....M/F2 Wire Assy,                       |
| 20 .....R-070275.....Front Wheels & Bracket          | 42 .....R-470280.....Slide Pot Assy                        |
| 21 .....R-026105.....Rear Wheel & Bracket Assy       | 43 .....R-470241.....Speed Control Assy                    |
| 22 .....R-3040174.....Clamp Assy                     |  |