


Models: 612956 (610110) Power Nozzle



- | | | | | | |
|-----|-----------|----------------------------------|----|----------|---------------------------------|
| 1 | SS-71B | Solderless Connector, 100 pk (R) | 20 | R-598265 | Fiber Washer |
| 1A | NLA | Cord | 21 | R-598166 | Washer |
| 2 | R-400011 | Control Knob | 22 | NLA | Brush Mount |
| 3 | R-598718 | Retaining Ring | 23 | R-598245 | Washer |
| 4 | R-598602 | CAM | 24 | NLA | Roller Arm Assembly |
| 5 | R-598209A | Nozzle Body, w/ onserts | 25 | R-598711 | Retaining Ring |
| 6 | R-598201 | Bumper | 26 | R-598007 | Right Roller |
| 7 | R-880304 | Strain Relief | 27 | R-598008 | Left Roller |
| 8 | R-598009 | Wheel | 28 | R-598138 | Washer |
| 9 | R-598101 | Wheel Shaft | 29 | NLA | Roller Arm |
| 10 | R-598407 | Wheel Bracket | 30 | NLA | Swivel Adaptor Assy |
| 11 | R-598318 | Retaining Ring | 31 | NLA | Adaptor Retainer Assy |
| 12 | NLA | Roller Arm Retaining Plate | 32 | R-059800 | Motor |
| 13 | R-598115 | Screw | 33 | R-059824 | Brush Roll Assy, double bristle |
| 14 | R-598012 | Screw | 34 | R-059872 | Bearing Assy, left |
| 15 | R-598830 | Motor Bracket | 35 | R-059873 | Bearing Assy, right |
| 15A | NLA | Sound Absorbing Pad | 36 | R-059822 | Bottom Plate Assy |
| 16 | R-598014 | Motor Mounting | 37 | R-598707 | Sealing Gasket |
| 17 | R-598056 | Dirt Seal, belt | 38 | R-598708 | Strip Gasket |
| 18 | R-598231 | Roller Spring Arm | 39 | R-598774 | Bottom Plate Only |
| 19 | R-598260 | Belt | 40 | R-598743 | Screw |