



- 1 R-250100 Screw
- 2 R-503819 Screw
- 3 R-5200607 Gasket, handle
- 4 R-520180 Screw
- 4 R-520185 Screw, 085540, 085470
- 5 R-520310 Screw
- 6 R-520350 Cord Retainer
- 7 R-540145 Lower Motor Housing
- 8 R-620180 Pedal, switch
- 9 R-620185 Spring, switch
- 10 R-620215 Pivot Seal
- 11 R-620295 Cord Hook
- 12 R-720120 Cord Hook
- 13 R-720310 Belt
- 14 R-720325 Motor Grommet
- 15 R-720355 Bushing
- 16 R-820351 Pivot Clamp
- 17 R-999025 Power Cord
- 18 R-210385 Switch Assy
- 19 R-520125 Brush Roll Assy
- 20 R-540011 Lower Handle Assy
- 21 R-254014 Upper Motor Housing Assy
- 22 R-620147 Paper Bag, type D, 3 pack

- 23 R-530111 Cover, dirt passage
- 24 R-530120 Nozzle Guard
- 25 R-540160 Fan
- 26 R-543021 Nozzle Cover Assy
- 26 R-547021 Nozzle Cover Assy, 085470
- 27 R-540076 Motor
- 27 R-520077 Motor, 085440
- 28 NLA Nozzle Base Assy
- 29 R-540035 Handle Assy, upper
- 30 R-4028036 Extension Wand
- 31 R-502801 Crevice Tool
- 32 R-540050 Hose Cup
- 33 R-540060 Wand Cup
- 34 R-530050 Upper Tool Caddy Assy
- 34 R-520625 Upper Tool Caddy Assy, 085470
- 35 R-530200 Roller Lifter Assy
- 36 R-530400 Hose Assy
- 36 R-520623 Hose Assy, 085470
- 37 R-540010 Back Panel Assy
- 38 R-540016E Front Panel Assy
- 39 NLA 2 in 1 Tool
- 39 R-920215 2 in 1 Tool, 085470
- 40 R-520180 Screw