



Index	Part No.	Description
1	R-157260	Style 1 belt, 2 pack
2	R-502744	Nozzle name plate - black (08100, 08100Red, 08100RT, 08130PR, 08150, 08510)
2	NLA	Nozzle name plate - black (08100Red series D, 08100RedC, 08100RT series D, 08100RTC)
3	R-503004	Fan (08100, 08100Red, 08100RT, 08130PR, 08150, 08510)
3	R-503005	Fan (08100Red series D, 08100RedC, 08100RT series D, 08100RTC)
4	R-503261	Shaft (08100, 08100Red, 08100RT, 08130PR, 08150, 08510)
4	NLA	Shaft (08100Red series D, 08100RedC, 08100RT series D, 08100RTC)
5	R-503266	Seal, felt
6	R-503270	Nozzle guard
7	R-503303	Switch
7	NLA	Switch, 2-speed, 08130PR, 08510
8	R-503319	Screw, #8
9	R-010347	Type G bag
10	R-503618	Screw, #6
11	R-503791	Stone shield
12	R-503819	Screw, #8
13	NLA	Power cord, 25'
14	R-813340	DD Plus Cloth bag assembly - red with black

Index	Part No.	Description
14	R-050340	Cloth bag assembly - red with black
15	R-050221	Brush assembly
16	R-857010	Motor (08100, 08100Red, 08100RT, 08130PR, 08150, 08510All)
16	R-085702	Motor (08100Red series D, 08100RedC, 08100RT series D, 08100RTC)
17	R-550130	Housing assembly (08100, 08100Red, 08100RT, 08130PR, 08150, 08510)
17	NLA	Housing assembly (08100Red series D, 08100RedC, 08100RT series D, 08100RTC)
Accessories		
18	R-880262	Belt lifter (08100RT, 08130PR, 08150, 08510)
19	R-050282	Round brush (08130PR, 08510)
20	R-260280	Crevice tool (08100RT)
20	R-502801	Crevice tool, 8" (08130PR, 08150, 08510)
21	R-103830	Nozzle adapter (08100RT, 08100RTC, 08130PR, 08150, 08510)
22	R-0502846	Hose assembly (08100RT, 08100RTC, 08130PR, 08150, 08510)
	R-503409	HV Adapter with 2 bags
	R-502776	Wand
	R-500006	Bracket, wall mounting
	R-5036006	Shoulder strap
	R-M193	Attachment kit