



- 1.....R-250100Screw
- 2.....R-720430Screw
- 3.....R-720128Switch
- 4.....R-720310Belt
- 5.....R-720380Belt guide Clip
- 6.....R-863054Caster Pal Nut
- 7.....R-863060Handle Release, pedal
- 8.....R-863088Bumper
- 8.....R-865088Scuff Guard Bumper, 086350
- 9.....R-863095Motor Cover
- 10.....R-863109Motor Air Duct
- 11.....R-863112.....Motor Duct Seal
- 12.....R-863168Neon Lamp
- 13.....R-863130Strain Relief
- 14.....R-690350Hanlde Release Pedal, spring
- 15.....R-863295Switch Compartment Cover
- 16.....R-863307Nozzle Cover Felt
- 17.....R-863308Belt Cover Felt
- 18.....R-863335Hose Inlet
- 19.....R-863337Hose Inlet Retainer
- 20.....R-920015Cord Hook
- 21.....R-920035Crevice Tool
- 22.....R-920140Pivot Clamp
- 23.....R-997125Power Cord
- 24.....R-630172Motor
- 25.....R-863360Telescopic Wand
- 26.....R-863005Brush Roll Assy
- 27.....R-863044Nozzle Base Assy
- 28.....R-863038Caster
- 29.....R-863040Height Adjustment Assy
- 30.....R-863069Nozzle Cover Assy, 086300
- 30.....R-63069L.....Nozzle Cover Assy, 086305
- 30.....R-286356Nozzle Cover Assy, 086350
- 31.....R-863087Lower Hose Assy
- 32.....NLABack Panel Assy
- 33.....R-863175Tool Caddy Assy
- 34.....R-863235Hanlde Assy
- 35.....R-863400Corner Tool Assy
- 36.....R-863405Hose Assy
- 37.....R-920047Paper Bags, 3 Pack
- 38.....R-9863140Front Panel Assy, 086300
- 38.....R-863141Front Panel Assy, 086305
- 38.....R-986314Front Panel Assy, 086350
- 39.....R-863320Triangle Tool Assy
- 40.....R-863411Wand Adaptor
- 41.....R-863105Motor Grommet
- 42.....R-863115Bag Chamber Filter
- 43.....R-863120Front Panel Exhaust Filter
- 44.....R-690360Tool Clip
- 45.....R-9202152 in 1 Tool