

Models: EC-T4765, EC-T4770

● ELECTRICAL PARTS

1-1 S-991Motor Assembly
 1-2 S-992Carbon Brush
 1-3 S-206Motor Lead Wire
 1-4 NLACircuit Lead Wire
 1-5 S-074Power Cord
 1-6 S-557Fuse
 1-7 S-927Fuse Holder
 1-8 S-993Lead Wire, fuse holder
 1-9 S-994Triac PWB Assy, T4765
 1-9 S-995Triac PWB Assy, T4770
 1-10 ... S-549Body Switch
 1-11.... S-1000Lead Wire A, body switch
 1-12 ... S-1001Lead Wire S, body switch
 1-13 ... S-209Lamp
 1-14 ... S-1002Lamp Socket
 1-15 ... S-1003Power Control PWB Assy, T4770
 1-16 ... S-1004Indicate PWB Assy, T4770
 1-17 ... S-1005Sensor PWB Assy, T4770
 1-18 ... S-1006Power Control PWB Assy, T4765

● MECHANICAL PARTS

2-1 S-1007Air Valve Assy
 2-2 S-178Wheel
 2-3 S-1008Sensor Cover
 2-4 S-1009Handle Mounting Base
 2-5 S-1010Valve Spring
 2-6 S-115Wheel Shaft
 2-7 S-1011Filter, secondary
 2-8 S-112Vibration-Proof Rubber
 2-9 S-646Vibration-Proof Fix Rubber
 2-10 ... S-1012Pipe Clamp
 2-11.... S-570Sound-Proof Sponge, motor sound
 2-12 ... S-1013Body Packing
 2-13 ... S-1014Seal Tape M
 2-14 ... S-1015Seal Tape N
 2-15 ... S-1258Valve
 2-16 ... S-571Leg Assembly TA
 2-17 ... S-572Leg Assembly TB
 2-18 ... S-1016Clean Filter A
 2-19 ... S-1017Reflection Plate
 2-20 ... S-1018Valve Cover
 2-21 ... S-101Dust Meter Assembly
 2-22 ... S-1019Knob Sheet
 2-23 ... S-1020Indicator Cover, dust meter
 2-24 ... S-1021HEPA-type Filter L
 2-25 ... S-1022HEPA-type Filter R
 2-26 ... S-1023Panel Holder, pipe
 2-27 ... S-0018Brush Roll Assembly
 2-28 ... S-585Agitator Rotor Assy
 2-29 ... S-1025Agitator Shaft Assy
 2-30 ... S-1026Agi-Support A Assy
 2-31 ... S-1027Agi-Support B Assy
 2-32 ... S-134Brush Rotor A

2-33 ... S-589Brush Rotor B14, main rotor
 2-34 ... S-1028Belt Stopper 3
 2-35 ... S-1029Pedal L, plastic
 2-36 ... S-1030Pedal Support, metal
 2-37 ... S-1031Pedal Spring
 2-38 ... S-1032Pedal Shaft
 2-39 ... S-1033B/C Plate Assy, welded
 2-40 ... S-1034Belt Lever 2nd Assy
 2-41 ... S-1035Belt Cover L
 2-42 ... S-1036B/C Lever Support
 2-43 ... S-1037B/C Crank
 2-44 ... S-1038B/C Cam
 2-45 ... S-1039B/C Spring
 2-46 ... S-1040B/C Plate Shaft
 2-47 ... S-1041Lever
 2-48 ... S-188Bottom Plate Knob
 2-49 ... S-1042Bottom Plate, metal
 2-50 ... S-148Bottom Plate Spring, knob
 2-51 ... S-189Roller
 2-52 ... S-149Shaft, roller
 2-53 ... S-1043Seal Tape F
 2-55 ... S-160Seal Tape F
 2-56 ... S-1044Seal Tape H
 2-57 ... S-1045Seal Tape U
 2-58 ... S-1046Seal Tape R
 2-59 ... S-190Pulley Cover
 2-60 ... S-1261Foot Pedal, rug/floor
 2-61 ... S-702Flat Belt M
 2-62 ... S-128B/C Shaft, for B/C lever
 2-63 ... S-1262Body Support, metal
 2-64 ... S-1049Belt Stopper
 2-65 ... S-1050Vibration-Proof Rubber
 2-66 ... S-1051B/C Plate Rubber
 2-67 ... S-1052Clamp Spring
 2-68 ... S-213Hanger Spring, cord
 2-69 ... S-1053Lower Hanger, cord
 2-70 ... S-1054Upper Hanger
 2-71 ... S-1055Seal Tape P, T4765
 2-71 ... S-1056Seal Tape Z, T4770
 2-72 ... S-1057Seal Tape Q
 2-73 ... S-1058Seal Tape V
 2-74 ... S-1059Seal Tape W
 2-75 ... S-1060Seal Tape Y

● EXTERNAL PARTS

3-1 S-1061Main Body
 3-2 S-1062Valve Coper 2
 3-3 S-1063Lens
 3-4 S-1064Filter Cover L
 3-5 S-1065Filter Cover R
 3-6 S-1066Dust Cover, T4765
 3-6 S-1067Dust Cover, T4770
 3-7 S-1068Clamp Knob
 3-8 S-1069Panel, T4765

3-8 S-1070Panel, T4770
 3-9 S-1071Slide Knob
 3-10 ... S-1072Indicator Plate
 3-11.... S-1073LED Lens 1, auto ind., T4770
 3-12 ... S-1074LED Lens 2, dirt ind., T4770
 3-13 ... S-1075Knob Cover, T4770
 3-14 ... S-1076Motor Cover
 3-15 ... S-1077Nozzle Head L., 14"
 3-16 ... S-1078Bumper L
 3-17 ... S-1079Brush Base, brush part
 3-18 ... S-1080Upholstery Tool
 3-19 ... S-1081Extensionm Pipe F, front/black
 3-20 ... S-1082Extension Pipe R, rear/grey
 3-21 ... S-1083Hose Assy, extension hose
 3-22 ... S-1084Nozzle Hose, blow-type
 3-23 ... S-1085Front Handle
 3-24 ... S-1086Rear Handle
 3-25 ... S-1087Hole Cover
 3-26 ... S-1088Crevice Tool
 3-27 ... S-1089Switch Knob

● MISCELLANEOUS

4-1 S-007Paper Bag, 3 pack
 4-2 S-1090Feature Sticker, T4765
 4-2 S-1091Feature Sticker, T4770
 4-3 S-1092Name Plate, T4765
 4-3 S-1093Name Plate, T4770

● SCREWS, NUTS AND WASHERS

5-1 S-200Nut
 5-2 S-238E-Ring
 5-3 S-641Screw
 5-4 S-202Screw
 5-5 S-203Screw
 5-6 S-204Screw
 5-7 S-204Screw
 5-8 S-546Screw
 5-9 S-199Nut
 5-10 ... S-761Screw
 5-11.... S-238E-Ring
 5-12 ... S-1095Special Screw, B-stopper
 5-13 ... S-1096Spring Washer
 5-14 ... S-1097Washer
 5-15 ... S-201Speed Nut, roller
 5-16 ... S-233Washer, cord hanger
 5-17 ... S-198Wave Washer, B/C plate assy
 5-18 ... S-125Special Screw
 5-19 ... S-236Screw
 5-20 ... S-1098Washer, B/C lever
 5-21 ... S-233Washer, B/C lever
 5-22 ... S-1099Special Screw
 5-23 ... S-197Washer



Pay by Credit Card

HESCO ACCEPTS: VISA, MASTERCARD, DISCOVER, BRAVO, PRIVATE ISSUE AND AMERICAN EXPRESS