


Models: EC-12TX3, EC-12TX3B, EC-12TX8, EC-12TX8B, EC-12TX6, EC-12SX2, EC-12SX3, EC-12SX6, EC-TU2603, EC-TU2608, EC-TU2705S, EC-TU4606



Models: EC-12TX3, EC-12TX3B, EC-12TX8, EC-TX8B, EC-12TX6, EC-12SX2, EC-12SX3, EC-12SX6, EC-TU2603, EC-TU2608, EC-TU2705S, EC-TU4606

ELECTRICAL PARTS

1-1S-017.....Motor Assy, 12TX8, 12TX6, 12TX3
 1-1S-906.....Motor Assy, 12TX8B, 12TX3B
 1-1S-554.....Motor Assy, 12SX2
 1-1S-020.....Motor Assy, 12SX6
 1-1S-950.....Motor Assy, TU2603, TU2608, TU2705S, TU4606
 1-2S-091.....Carbon Brush, 12TX8, 12TX6, 12TX3
 1-2S-912.....Carbon Brush, 12TX8B, 12TX3B, 12SX2
 1-2S-239.....Carbon Brush, 12SX3, 12SX6
 1-2NLA.....Carbon Brush, TU2603, TU2608, TU2705S, TU4606
 1-3S-074.....Power Cord, 12TX8, TU2608, TU2705S
 1-3S-704.....Power Cord, 12TX3B
 1-3S-074.....Power Cord, 12TX8B
 1-3S-075.....Power Cord, 12SX2, 12TX6, 12TS6, TU2603
 1-3S-551.....Power Cord, 12SX3, 12TX3
 1-3S-.....Power Cord, TU4606
 1-4S-206.....Lead Wires, motor
 1-6S-208.....Lead Wires, lamp
 1-7S-095.....Power Control Assy, 12TX8/B, TU2608, TU4606
 1-8S-096.....Triac Assy, 12TX8/B, TU2608, TU4606
 1-9S-030.....Main Switch
 1-9S-549.....Main Switch, TU2608, TU2705S
 1-9S-029.....Micro Switch, 12TX3B, 12TX8B, TU4606
 1-10S-209.....Lamp
 1-12S-211.....Fuse
 1-12S-557.....Fuse, 12SX3, 12TX3B, 12TX8B, TU2603, TU2608, TU2705S, TU4606
 1-13S-098.....Fuse Holder, 12TX3
 1-13S-927.....Fuse Holder, TU2705S
 1-13S-558.....Fuse Holder, 12TX3B, 12TX8B, TU2603, TU2608, TU4606

MECHANICAL PARTS

2-1S-213.....Spring, cord hanger
 2-2S-101.....Dust Indicator Assy
 2-4NLA.....Meter Pipe Connector, 12TX8
 2-5NLA.....Main Body Packing 'M'
 2-7S-242.....Main Body Packing 'L', 12SX6
 2-8S-104.....Handle Fixing Plate
 2-9S-106.....Indicating Plate
 2-9S-973.....Indicating Plate, TU4606
 2-10S-107.....Panel Seal
 2-11S-108.....Body Seal, 12SX2, 12SX3
 2-12S-109.....Motor Cover Seal
 2-13S-110.....Air Valve Assy
 2-14S-084.....Secondary Filter, 12TX6, 12SX2, 12SX3, 12SX6, 12TX3B
 2-15S-111.....Clamp Spring
 2-16S-112.....Vibration-Proof Rubber
 2-16S-569.....Vibration-Proof Rubber, 12SX2
 2-16S-243.....Vibration-Proof Rubber, 12SX3, 12SX6
 2-17S-646.....Vibration-Proof Fixing Rubber
 2-17S-113.....Vibration-Proof Fixing Rubber, 12TX8, 12SX6, TU4606
 2-17S-244.....Vibration-Proof Fixing Rubber, 12SX3, 12SX6
 2-17S-646.....Vibration-Proof Fixing Rubber, TU2705S
 2-18S-114.....Sound-Proof Sponge
 2-19S-115.....Wheel Shaft
 2-20S-116.....Leg Assy, TA
 2-20S-571.....Leg Assy, TA, 12SX2
 2-21S-117.....Leg Assy, TB

2-21S-572.....Leg Assy, TB, 12SX2
 2-22S-036.....Clean Filter
 2-22S-573.....Clean Filter, 12SX2
 2-22S-873.....Clean Filter, TU2705S, TU2603/8
 2-23S-245.....Motor Shelter Plate, 12SX6
 2-24S-246.....Packing 'M', 12SX3, 12SX6
 2-25S-118.....Body Support
 2-26S-119.....Belt Stopper
 2-26S-162.....Belt Stopper, 12TX3B, 12TX8B, 12SX2, TU2705S
 2-26S-120.....Belt Stopper 3, TU2603, TU2608
 2-27S-215.....Reflection Plate
 2-28S-216.....Lamp Support
 2-29S-217.....Cord Bushing, nozzle head
 2-29S-928.....Cord Bush, nozzle hd, TU2705S
 2-30S-218.....Heat-Proof Plate
 2-30S-578.....Heat-Proof Plate, TU2608, TU2705S
 2-31S-123.....Belt Guide Pin
 2-32S-130.....Pedal Support
 2-33S-131.....Pedal Spring
 2-34S-132.....Pedal Shaft
 2-35S-009.....Agitator Assy
 2-35S-001.....Agitator Assy, EC-TU4606
 2-35S-584.....Agitator Assy, 12SX2
 2-36S-133.....Agitator Pipe Assy
 2-36S-918.....Agitator Pipe Assy, 12SX2
 2-37S-141.....Agitator Shaft
 2-38NLA.....Agitator Support 'A'
 2-39NLA.....Agitator Support 'B'
 2-40S-144.....Main Pulley Assy
 2-41S-140.....Brush Rotor 'B'
 2-41S-590.....Brush Rotor 'B', 12SX2
 2-42S-146.....Brush Base Assy
 2-43S-149.....Roller Shaft
 2-44S-159.....Seal Tape 'E'
 2-45S-151.....Seal Tape 'B'
 2-46S-152.....Seal Tape 'C'
 2-47S-013.....Belt, flat
 2-47S-702.....Belt, flat, 12SX2, 12TX3B, 12TX8B, TU2603, TU2608, TU2705S
 2-47S-894.....Belt, 12SX3
 2-48S-162.....Belt Guide Plate
 2-49S-154.....Body Seal Tape 'S'
 2-50S-155.....Body Seal Tape 'L'
 2-51S-247.....Seal Tape 'D', 12TX6, 12SX2, 12SX3, 12SX6, TU2603, TU2608
 2-52S-156.....Body Seal Tape 'S1'
 2-53S-157.....Body Seal Tape 'L1'
 2-53S-874.....Body Seal Tape 'L1', 12TX3/8B, 12SX2
 2-54S-158.....Seal Tape 'G'
 2-55S-160.....Seal Tape 'F'
 S-099.....Switch Rod, TU4606
 S-100.....Switch Knob Spring, TU4606

EXTERNAL PARTS

3-1S-163.....Grip, right
 3-2S-164.....Grip, left
 3-3S-248.....Grip Cover
 3-4S-219.....Hanger Top
 3-5S-220.....Hanger, bottom
 3-6S-221.....Handle Pipe
 3-7S-168.....Body Cap
 3-8S-249.....Main Body
 3-8S-222.....Main Body, 12TX3B, 12TX8B, TU2705S, TU4606
 3-8S-952.....Main Body, TU2603, TU2608
 3-9S-250.....Panel, 12TX8
 3-9S-251.....Panel, 12TX6
 3-9S-919.....Panel, 12SX2
 3-9S-252.....Panel, 12SX3, 12SX6
 3-9S-887.....Panel, 12TX3B

3-9S-886.....Panel, 12TX8B
 3-9S-875.....Panel, TU2603
 3-9S-877.....Panel, TU2608
 3-9S-929.....Panel, TU2705S
 3-9S-935.....Panel, TU4606
 3-10S-173.....Slide Knob, 12TX8/B, TU2608, TU4606
 3-11S-224.....Dust Cover, 12TX3B, 12TX8B
 3-11S-878.....Dust Cover, TU2603, TU2608
 3-11S-930.....Dust Cover, TU2705S,
 3-11S-936.....Dust Cover, TU4606
 3-12S-611.....Clamp Knob
 3-12S-255.....Clamp Knob, 12TX8
 3-12S-256.....Clamp Knob, 12SX6
 3-12S-879.....Clamp Knob, TU2603, TU2608
 3-13S-176.....Hose
 3-14S-177.....Hose Elbow
 3-15S-178.....Wheel
 3-16S-951.....Motor Cover
 3-16S-257.....Motor Cover, 12TX8, 12TX6
 3-16S-258.....Motor Cover, 12SX6
 3-17S-044.....Nozzle Head 'M' Assy, 12TX8
 3-17S-045.....Nozzle Head 'M' Assy, 12TX6
 3-17S-920.....Nozzle Head 'M' Assy, 12SX2
 3-17S-046.....Nozzle Head 'M' Assy, 12SX6
 3-17S-880.....Nozzle Head "M" Assy, TU2603, TU2608
 3-17S-931.....Nozzle Head 'M' Assy, TU2705S
 3-17S-813.....Nozzle Head 'M' Assy, 12TX3B, 12TX8B, TU4606
 3-18S-259.....Lens
 3-18S-921.....Lens, 12SX2
 3-18S-897.....Lens, 12SX3
 3-18S-881.....Lens, 12TX3B, TU2603
 3-19S-184.....Pedal 'L'
 3-20S-187.....Belt Cover 'M'
 3-20S-937.....Belt Cover 'L', TU4606
 3-21S-028.....Bottom Plate 'M'
 3-21S-027.....Bottom Plate 'L', TU4606
 3-22S-189.....Roller
 3-23NLA.....Head Shelter Plate
 S-922.....Extension Wand, 12SX2
 S-923.....Hose Assy, 12SX2
 S-924.....Nozzle Assy, 12SX2
 S-630.....Nozzle Brush, 12SX2
 S-631.....Upholstery Nozzle, 12SX2

MISCELLANEOUS

4-3S-007.....Paper Bag, 3 pack
 4-3S-751.....Paper Bag, ea
 4-5S-230.....Service Label
 4-7S-926.....Name Plate, 12SX2
 4-7S-263.....Name Plate, 12TX8
 4-7S-264.....Name Plate, 12TX6
 4-7S-265.....Name Plate, 12SX6
 4-7S-885.....Name Plate, TU2603
 4-7S-884.....Name Plate, TU2608
 4-7S-938.....Name Plate, TU4606
 4-7S-933.....Name Plate, TU5705S

SCREWS, NUTS & WASHERS

5-1S-195.....Special Screw, handle fixing
 5-2S-233.....Washer, cord hanger and clamp knob mounting
 5-3S-197.....Washer, wheel shaft & agitator
 5-4S-266.....B/P Fixing Screw
 5-5S-200.....Nut
 5-6S-205.....E-Clip
 5-7S-238.....E-Clip
 5-8S-201.....Speed Nut
 5-9S-236.....Screw
 5-10S-203.....Screw
 5-11S-204.....Screw
 5-12S-237.....Screw
 5-13S-236.....Screw
 5-14S-267.....Screw