


Models: EC-14TWT6, EC-14TAT6, EC-12TWT6,
EC-12TWT4, EC-12TWT2, EC-12TXT2, EC-12SXT4B, EC-T4840



Models: EC-14TWT6, EC-14TAT6, EC-12TWT6,
EC-12TWT4, EC-12TWT2, EC-12TXT2, EC-12SXT4B, EC-T4840

● ELECTRICAL PARTS

- 1-1 S-991 Motor Assy
- 1-1 S-554 Motor Assy, 12SXT4B
- 1-1 S-906 Motor Assy, 14TWT6, 14TAT6, 12TWT6
- 1-1 S-906 Motor Assy, T4840
- 1-2 NLA Carbon Brush
- 1-2 S-552 Carbon Brush, 12SXT4B
- 1-2 S-912 Carbon Brush, 14TWT6, 14TAT6, 12TWT6
- 1-3 S-837 Power Cord, 12TWT2
- 1-3 S-838 Power Cord, 12TXT2, 12SXT4B
- 1-3 S-839 Power Cord, 12TWT6, 12TWT4
- 1-3 S-074 Power Cord
- 1-4 S-206 Motor Lead Wires
- 1-6 S-208 Lamp Lead Wires
- 1-7 S-095 Power Control Assy, 14TWT6, 14TAT6, 12TWT6
- 1-8 S-805 Triac Assy, 14TWT6, 14TAT6, 12TWT6
- 1-9 S-549 On/Off Switch
- 1-9 S-907 On/Off Switch, 14TWT6, 14TAT6, 14TWT6, 12TWT4
- 1-9 S-030 On/Off Switch, T4840
- 1-10 S-840 Lamp
- 1-10 S-209 Lamp, T4840
- 1-11 S-556 Lamp Socket
- 1-11 S-947 Lamp Socket, T4840
- 1-12 S-557 Fuse
- 1-13 S-558 Fuse Holder
- 1-13 S-927 Fuse Holder, T4840

● MECHANICAL PARTS

- 2-1 S-101 Dust Indicator Assy
- 2-2 S-559 Dust Indicator Base, 14TWT6, 14TAT6, 12TWT6
- 2-3 S-560 Meter Pipe Connector, 14TWT6, 14TAT6, 12TWT6
- 2-4 S-561 Handle Mounting Base
- 2-5 S-702 Belt, flat
- 2-6 S-154 Body Seal Tape S
- 2-7 S-155 Body Seal Tape L
- 2-8 S-213 Spring, cord hanger
- 2-9 S-563 Indicating Plate, 14TWT6, 14TAT6, 12TWT6
- 2-10 S-564 Panel Seal
- 2-11 S-565 Body Seal
- 2-12 S-566 Seal, motor cover
- 2-13 S-245 Motor Shelter Plate, 12SXT4B
- 2-14 S-567 Secondary Filter, 14TWT6, 14TAT6, 12TWT6, T4840
- 2-15 S-111 Clamp Spring
- 2-16 S-112 Vibration-Proof Rubber
- 2-16 S-569 Vibration-Proof Rubber, 12SXT4B
- 2-17 S-646 Vibration-Proof Fixing Rubber
- 2-18 S-570 Sound-Proof Sponge
- 2-19 S-115 Wheel Shaft
- 2-20 S-571 Leg Assembly TA
- 2-21 S-572 Leg Assembly TB
- 2-22 S-573 Clean Filter
- 2-23 S-574 Body Support
- 2-24 S-575 Belt Stopper
- 2-25 S-576 Reflection Plate
- 2-26 S-577 Lamp Support
- 2-27 S-217 Cord Bushing, nozzle head
- 2-28 S-578 Heat-Proof Plate
- 2-29 S-579 Head Pipe
- 2-31 S-125 Screw, bottom plate
- 2-32 S-580 Belt Change Lever Support
- 2-33 S-581 Belt Change Plate
- 2-34 S-128 Belt Change Shaft
- 2-35 S-582 Belt Change Spring
- 2-36 S-130 Pedal Support

- 2-37 S-131 Pedal Spring
- 2-38 S-132 Pedal Shaft
- 2-39 S-584 Brush Roll Assy
- 2-39 S-0018 Brush Roll Assy, 14TWT6, 14TAT6
- 2-39 S-1247 Brush Roll Assy, T4840
- 2-40 S-133 Rotor Assy
- 2-40 S-585 Rotor Assy, 14TWT6, 14TAT6, T4840
- 2-41 S-134 Idling Pulley Assy, 14TWT6, 14TAT6
- 2-42 S-141 Shaft Assy
- 2-42 S-135 Shaft Assy, 14TWT6, 14TAT6
- 2-42 S-1025 Shaft Assy, T4840
- 2-43 S-587 Agitator Support A
- 2-44 NLA Agitator Support B
- 2-44 S-588 Agitator Support B, 14TWT6, 14TAT6, T4840
- 2-45 S-120 Felt Stopper 3
- 2-46 S-139 Brush Rotor A, 14TWT6, 14TAT6, T4840
- 2-47 S-590 Brush Rotor B
- 2-47 S-589 Brush Rotor B, 14TWT6, 14TAT6, T4840
- 2-50 S-148 Spring, bottom plate
- 2-51 S-149 Roller Shaft
- 2-52 S-150 Seal Tape A
- 2-53 S-151 Seal Tape B
- 2-55 S-121 Belt, vibration-proof rubber
- 2-56 S-246 M Packing
- 2-57 S-159 Seal Tape E
- 2-58 S-160 Seal Tape F
- 2-59 S-158 Seal Tape G
- 2-60 S-247 Seal Tape D
- 2-61 S-162 Belt Guide Plate
- S-1245 U-Seal, T4840
- S-247 Seal Tape D, T4840
- S-1246 Seal Tape H, T4840
- S-1248 P Spacer, T4840

● EXTERNAL PARTS

- 3-1 S-591 Front Handle
- 3-2 S-592 Rear Handle
- 3-3 S-593 Upper Hanger
- 3-4 S-594 Hose Clamp
- 3-5 S-595 Pipe Clamp
- 3-6 S-596 Brush Clamp
- 3-7 S-564 Panel Seal
- 3-8 S-911 Main Body
- 3-8 S-598 Main Body, 12TWT2, 12TXT2, 12SXT4B
- 3-8 S-1249 Main Body, T4840
- 3-9 S-956 Panel, 14TWT6
- 3-9 S-841 Panel, 12TWT6
- 3-9 S-842 Panel, 14TAT6
- 3-9 S-843 Panel, 12TWT4
- 3-9 S-844 Panel, 12TWT2, 12TXT2
- 3-9 S-845 Panel, 12SXT4B
- 3-9 S-1250 Panel, T4840
- 3-10 S-604 Slide Knob
- 3-11 S-608 Dust Cover, 12SXT4B
- 3-11 S-846 Dust Cover, 14TWT6
- 3-11 S-847 Dust Cover, 12TWT6, 12TWT4
- 3-11 S-848 Dust Cover, 12TWT2, 12TXT2
- 3-11 S-849 Dust Cover, 14TAT6
- 3-11 S-1251 Dust Cover, T4840
- 3-12 S-850 Clamp Knob, 14TAT6
- 3-12 S-609 Clamp Knob, 14TWT6
- 3-12 S-610 Clamp Knob, 12TWT6, 12TWT4
- 3-12 S-611 Clamp Knob, 12SXT4B
- 3-12 S-851 Clamp Knob, 12TWT2, 12TXT2
- 3-12 S-1252 Clamp Knob, T4840
- 3-13 S-612 Hose Assembly
- 3-14 NLA Head Shelter Plate
- 3-15 S-178 Wheel
- 3-16 S-852 Motor Cover, 14TAT6

- 3-16 S-613 Motor Cover, 14TWT6
- 3-16 S-615 Motor Cover, 12SXT4B
- 3-16 S-853 Motor Cover, 12TWT6, 12TWT4
- 3-16 S-855 Motor Cover, 12TWT2, 12TXT2
- 3-16 S-1253 Motor Cover, T4840
- 3-17 S-856 Nozzle Head L Assy, 14TAT6
- 3-17 S-857 Nozzle Head L Assy, 14TWT6
- 3-17 S-1254 Nozzle Head L Assy, T4840
- 3-17 S-0520 Nozzle Head M Assy, 12TWT6, TWT4
- 3-17 S-883 Nozzle Head M Assy, 12TWT2, 12TXT2
- 3-17 S-858 Nozzle Head M Assy, 12SXT4B
- 3-18 S-620 Lens L
- 3-18 S-621 Lens M
- 3-18 S-859 Lens M, 12SXT4B
- 3-18 S-860 Lens M, 12TXT2
- 3-19 S-076 Pedal L
- 3-20 S-624 Belt Change Lever
- 3-21 S-186 Belt Cover L, 14TWT6, 14TAT6, T4840
- 3-21 S-187 Belt Cover M
- 3-22 S-625 Bottom Plate L, 14TAT6, 14TAT6, T4840
- 3-22 S-626 Bottom Plate M
- 3-23 S-188 Knob, bottom plate
- 3-24 S-189 Roller
- 3-25 S-190 Pulley Cover
- 2-26 S-627 Out Extension Pipe
- 3-27 S-640 In Extension Pipe
- 3-28 NLA Crevice Tool
- 3-28 S-876 Crevice Tool, T4840
- 3-29 S-630 Nozzle Brush
- 3-30 S-631 Upholstery Nozzle
- 3-30 S-631 Upholstery Nozzle, T4840
- 3-31 S-632 Hole Cover
- 3-32 S-815 Plastic Wand, 14TWT6, 14TAT6, 12TWT6

● MISCELLANEOUS

- 4-2 S-007 Paper Bag, 3 pack
- 4-3 S-862 Feature Sticker
- 4-3 S-864 Feature Sticker, 12TWT2, 12TXT2
- 4-3 S-865 Feature Sticker, 12SXT4B
- 4-3 S-882 Feature Sticker, T4840
- 4-4 S-866 Name Plate, 14TAT6
- 4-4 S-867 Name Plate, 12TXT2
- 4-4 S-868 Name Plate, 14TWT6
- 4-4 S-869 Name Plate, 12TWT6
- 4-4 S-870 Name Plate, 12TWT4
- 4-4 S-871 Name Plate, 12TWT2
- 4-4 S-872 Name Plate, 12SXT4B
- 4-4 S-1255 Name Plate, T4840

● SCREWS, NUTS and WASHERS

- 5-1 S-639 Special Screw, handle fixing
- 5-2 S-233 Washer, upper hanger/clamp knob
- 5-3 S-197 Washer, wheel shaft
- 5-4 S-198 Wave Washer
- 5-5 S-199 Special Nut
- 5-6 S-200 Nut
- 5-7 S-201 Speed Nut
- 5-8 S-202 Screw
- 5-9 S-203 Screw
- 5-10 S-204 Screw
- 5-11 S-641 Screw
- 5-12 S-236 Screw
- 5-13 S-642 Screw
- 5-14 S-643 E-Crip
- 5-15 S-238 E-Crip
- 5-16 S-644 Screw
- 5-17 S-202 Screw