



Models: EC-TU2807, EC-TU2809

## ■ ELECTRICAL PARTS

1-1	S-1100	Motor assembly
1-2	S-992	Carbon brush
1-3	S-206	Motor lead wire
1-4	S-207	Circuit lead wire, EC-TU2807
1-5	S-075	Power cord, EC-TU2807
1-5	S-074	Power cord, EC-TU2809
1-6	S-557	Fuse
1-7	S-927	Fuse holder
1-8	S-993	lead wire
1-9	S-994	Triac PWB Assembly, EC-TU2809
1-10	S-804	On/off switch
1-11	S-1000	lead wire A, on/off switch
1-12	S-1001	lead wire S, on/off switch
1-13	S-1496	Lamp
1-14	S-1002	Lamp socket
1-15	S-1006	Power control PWB assembly, EC-TU2809

## ■ MECHANICAL PARTS

2-1	S-1108	Air valve assembly
2-2	S-178	Wheel
2-3	S-1008	Sensor cover
2-4	S-1009	Handle mounting base
2-5	S-1010	Valve spring
2-6	S-115	Wheel shaft
2-7	S-1011	Secondary filter
2-8	S-112	Vibration proof rubber
2-9	S-646	Vibration proof fixing rubber
2-10	S-863	Pipe clamp
2-11	S-570	Sound proof sponge, motor sound
2-12	S-1013	Body packing
2-13	S-1014	Seal tape M
2-14	S-1015	Seal tape N
2-15	S-1345	Valve
2-16	S-1110	Leg assembly TA
2-17	S-1111	Leg assembly TB
2-18	S-1016	Clean filter A
2-19	S-1017	Reflection plate
2-20	S-1018	valve cover
2-21	S-101	Dust indicator assembly, EC-TU2807
2-22	S-100	Switch knob spring
2-23	S-1020	Indicator (dust meter) cover, EC-TU2807
2-24	S-1021	HEPA filter L
2-25	S-1022	HEPA filter R
2-26	S-1115	Body peal seal
2-27	S-1285	Agitator assembly
2-28	S-1348	Agitator rotor assembly
2-29	S-1341	Agitator shaft
2-30	S-1350	Agitator support
2-31	S-1351	Bearing holder assembly
2-32	S-1059	Seal tape W
2-33	S-1060	Seal tape Y
2-34	S-120	Belt stopper 3
2-35	S-1029	Pedal L, plastic
2-36	S-1030	Pedal support, metal
2-37	S-1031	Pedal spring
2-38	S-1032	Pedal shaft
2-39	S-1058	Seal tape V
2-40	S-1055	Seal tape P
2-41	S-1535	Belt cover
2-42	S-1343	valve case
2-43	S-1353	Head valve
2-44	S-1331	Valve spring
2-45	S-1332	valve cover
2-46	S-1053	Lower hanger, cord
2-47	S-1054	Upper hanger
2-48	S-188	Bottom plate knob
2-49	S-1697	Bottom plate, metal plate
2-50	S-148	Bottom plate spring, knob
2-51	S-1117	Roller
2-52	S-149	Roller shaft
2-53	S-1509	Seal tape B
2-54	S-1510	Seal tape C
2-55	S-247	Seal tape D
2-56	S-159	Seal tape E
2-57	S-1441	Seal tape G98
2-58	S-1046	Seal tape R

2-59	S-1356	Head shelter plate
2-60	S-1334	Head pipe
2-61	S-702	Flat belt M
2-62	NLA	Body packing S, EC-TU2807
2-63	S-1262	Body support, metal
2-64	S-1049	Belt stopper
2-65	S-123	Belt guide pin
2-66	S-1230	Stopper rubber
2-67	S-1052	clamp spring
2-68	S-213	Hanger spring, cord
2-69	S-1120	Lower hanger, cord
2-70	S-863	Upper hanger
2-71	S-1055	Seal tape P
2-72	S-1121	valve seal
2-73	S-1019	Knob sheet
2-74	S-1059	Seal tape W
2-75	S-1060	Seal tape Y
2-76	S-1122	Actuator support
2-77	s-105	Actuator
2-78	S-748	Screw mounting plate
2-79	S-805	Switch lod

## ■ EXTERNAL PARTS

3-1	S-1061	Main body
3-2	S-1062	Valve cover 2
3-3	S-1063	lens
3-4	S-1442	Filter cover L
3-5	S-1443	Filter cover R
3-6	S-1444	Dust cover, EC-TU2807
3-7	S-1449	Clamp knob
3-8	NLA	Panel
3-9	S-604	Slide knob, EC-TU2809
3-10	S-563	Indicator plate, EC-TU2809
3-11	S-741	On/off switch knob
3-12	S-876	Crevice tool
3-13	S-1140	Hose hanger
3-14	S-1734	Motor cover
3-15	S-1735	Nozzle head
3-16	S-1078	Bumper L
3-17	S-1145	Nozzle brush W
3-18	S-1146	Nozzle assembly W
3-19	S-1447	Metal wand assembly
3-20	S-1148	Body cap
3-21	S-1149	Hose assembly
3-22	S-1084	Nozzle hose, blow type
3-23	S-1276	Right grip
3-24	S-1277	Left grip
3-25	S-1150	Handle pipe

## ■ MISCELLANEOUS

4-1	S-751	Paper bag
4-2	S-1151	feature sticker
4-3	S-1153	Name plate

## ■ SCREWS, NUTS AND WASHERS

5-1	S-200	Nut
5-2	S-643	E-ring
5-3	S-641	Screw
5-4	S-1692	Screw
5-5	S-1581	Screw
5-6	S-1440	Screw, black
5-7	S-204	Screw
5-8	S-546	Screw
5-9	S-199	Nut
5-10	S-761	Screw
5-11	S-238	E-ring
5-12	S-1095	Special screw, B-stopper
5-13	S-1279	Spring washer
5-14	S-1097	Washer
5-15	S-201	Speed nut, roller
5-16	S-233	Washer
5-17	S-198	Wave washer (B/C plate assembly)
5-18	S-125	Special screw
5-19	S-1439	Screw
5-20	S-1098	Washer, agitator assembly
5-21	S-233	Washer, hanger
5-22	S-1099	Special screw
5-23	S-1329	Washer