


Models: EC-4320, EC-4420

- | | | |
|--|---|--|
| 1 S-020 Motor Assembly | 28 S-300 Stopper, for notch of body, 4320 | 63 S-334 Pedal Mtg. Plate |
| 2 S-268 Carbon Brush | 29 S-038 Clean Filter | 64 S-335 Pedal Shaft (M) |
| 3 S-269 Nozzle Head 'M', w/ bumper, 4320 | 30 S-302 Fixing Rubber | 65 S-316 E-Ring |
| 3 S-270 Nozzle Head 'M', w/ bumper, 4420 | 31 S-303 Vibration-Proof Rubber | 66 S-337 Spring, pedal |
| 4 S-271 Lens 'M', 4420 | 32 S-304 Nozzle Head Holder | 67 S-338 Lamp, 4420 |
| 5 S-272 Lamp Cover, 4420 | 33 S-305 Wire Assembly (1) | 68 S-339 Lamp Socket, 4420 |
| 6 S-273 Main Body, w/ seal tape | 34 S-306 Wire Assembly (2), 4420 | 69 S-340 Reflecting Plate (M), 4420 |
| 7 S-274 Dust Cover, 4320 | 35 S-307 Screw, bottom plate | 70 S-341 Heat-Proof Plate, 4420 |
| 7 S-275 Dust Cover, 4420 | 36 S-308 Shelter Plate, w/ seal tape | 71 S-342 Cord Bushing, nozzle head, 4420 |
| 8 S-276 Motor Cover | 37 S-309 Felt 'M' | 72 S-343 Lamp Mtg. Plate, 4420 |
| 9 S-277 Pedal | 38 S-086 Agitator Assembly (M) | 73 S-344 Caution Label, dust cover |
| 10 S-053 Wheel | 39 S-311 Agitator Pipe (M) | 74 S-345 Dust Indicator Mtg. Plate, 4420 |
| 11 S-279 Panel, 4320 | 40 S-312 Agitator Brush (M) | 75 S-346 Belt Guide Sleeve |
| 11 S-280 Panel, 4420 | 41 S-313 Agitator Pulley (M), w/ bearing | 76 S-347 Screw |
| 12 S-281 Decoration Plate, for panel, 4320 | 42 S-314 Agitator Holder, w/ bearing | 77 S-348 Leg Assembly, left |
| 12 S-282 Decoration Plate, for panel, 4420 | 43 S-315 Spacer (M) | 78 S-349 Leg Assembly, right |
| 13 S-064 Power Cord, 4320 | 44 S-316 E-Ring | 79 S-350 Leg Mtg. Plate |
| 13 S-392 Power Cord, 4420 | 45 S-317 Agitator Shaft Assembly | 80 S-351 Screw |
| 14 S-285 Cord Bushing, for main body | 46 S-318 End Plate | 81 S-057 Pipe |
| 15 S-286 Switch, on/off | 47 S-319 End Plate (M) | 82 S-353 Grip Cover |
| 16 S-287 Dust Indicator Assembly, 4420 | 48 S-010 Belt, flat | 83 S-354 Grip, right |
| 17 S-288 Name Plate | 50 S-087 Bottom Plate | 84 S-355 Grip, left |
| 17 S-289 Name Plate | 51 S-323 Rear Belt Cover | 85 S-058 Cord Hanger, bottom |
| 18 S-290 Hose Connector | 53 S-324 Main Body Holder | 86 S-059 Cord Hanger, upper |
| 19 S-291 Pipe Fixing Plate | 54 S-325 Suction Hose | 87 S-358 Spring, cord hanger |
| 20 S-292 Secondary Filter | 55 S-007 Paper Bag, 3 pack | 88 S-359 Washer, cord hanger mtg. |
| 21 S-293 Sealing Packing (1) | 56 S-327 Sound-Proof Sponge | 89 S-360 Screw |
| 22 S-294 Sealing Packing (2) | 57 S-328 Ad Label | 90 S-361 Screw |
| 23 S-295 Sealing Packing (3) | 58 S-329 Roller Shaft | 91 S-362 Screw, pipe mtg. |
| 24 S-296 Sealing Packing (4) | 59 S-330 Roller | 93 S-363 Service Label |
| 25 S-297 Wheel Shaft | 60 S-331 Speed Nut | 94 S-364 Washer |
| 26 S-298 E-Ring | 61 S-332 Spring, bottom plate | |
| 27 S-299 Washer | 62 S-333 Button, bottom plate | |

VACUUM REPAIR PARTS
CHEMICALS
CLEANING EQUIPMENT
WINDOW WASH SUPPLIES
MOTORS & PUMPS
CAR WASH SUPPLIES
CARPET CARE PRODUCTS

Over 40,000 items
at your fingertips!



CALL US TODAY
1-800-822-7467