



## ■ ELECTRICAL PARTS

1-1	S-555	Motor Assembly
1-2	S-553	Carbon Brush
1-3	S-093	Power Cord
1-4	S-801	Motor Lead Wire Assembly
1-5	S-802	Grounding Lead Wire Z
1-6	S-549	Main Switch
1-7	S-557	Fuse
1-8	S-558	Fuse Holder

## ■ MECHANICAL PARTS

2-1	S-104	Handle Fixing Plate
2-2	S-241	Main Body Packing S
2-3	S-161	Main Body Packing M
2-4	S-108	Body Seal
2-5	S-110	Air Valve Assembly
2-6	S-115	Wheel Shaft
2-7	S-154	Body Seal Tape S
2-8	S-155	Body Seal Tape L
2-9	S-107	Panel Seal
2-10	S-111	Clamp Spring
2-11	S-109	Motor Cover Seal
2-12	S-036	Clean Filter
2-13	S-084	Secondary Filter
2-14	S-116	Leg Assembly TA
2-15	S-117	Leg Assembly TB
2-16	S-112	Vibration-Proof Rubber
2-17	S-114	Sound-Proof Sponge
2-18	S-646	Vibration-Proof Fixing Rubber
2-19	S-702	Flat Belt M
2-20	S-119	Belt Stopper
2-21	S-118	Body Support
2-22	S-130	Pedal Support L
2-23	S-131	Pedal Spring
2-24	S-120	Belt Stopper 3
2-25	S-132	Pedal Shaft
2-26	S-121	Belt Vibration-Proof Rubber
2-27	S-002	Agitator Assembly
2-28	S-143	Agitator Support B
2-29	S-145	Brush Rotor B
2-30	S-133	Agitator Pipe Assembly
2-31	S-146	Brush Base Assembly
2-32	S-144	Main Pulley
2-33	S-141	Agitator Shaft
2-34	S-142	Agitator Support A
2-35	S-149	Roller Shaft
2-36	S-160	Seal Tape F
2-37	S-123	Belt Guide Pin
2-38	S-152	Seal Tape C

2-39	S-151	Seal Tape B
2-40	S-159	Seal Tape E
2-41	S-158	Seal Tape G

## ■ EXTERNAL PARTS

3-1	S-163	Grip, right
3-2	S-164	Grip, left
3-3	S-248	Grip Cover
3-4	S-166	Hanger C
3-5	S-167	Handle Pipe
3-6	S-168	Body Cap
3-7	S-808	Main Body
3-8	S-824	Panel
3-9	S-177	Hose Elbow
3-10	S-825	Dust Cover
3-11	S-811	Clamp Knob
3-12	S-176	Hose
3-13	S-826	Motor Cover
3-14	S-178	Wheel
3-15	S-827	Lens
3-16	S-813	Nozzle Head M Assembly
3-17	S-187	Belt Cover M
3-18	S-184	Pedal L
3-19	S-189	Roller
3-20	S-829	Bottom Plate M
3-21	S-191	Head Shelter Plate

## ■ MISCELLANEOUS

4-1	N/A	Operation Manual
4-2	S-817	Dust Bag
4-3	S-230	Service Label
4-4	S-818	Feature Sticker
4-5	S-832	Name Plate

## ■ SCREWS, NUTS AND WASHERS

5-1	S-195	Special Screw, handle fixing
5-2	S-196	Washer
5-3	S-197	Washer, wheel shaft
5-4	S-641	Screw
5-5	S-199	Special Nut, left hand screw-type
5-6	S-200	Nut
5-7	S-201	Speed Nut
5-8	S-202	Screw
5-9	S-203	Screw
5-10	S-204	Screw
5-11	S-820	Screw
5-12	S-2236	Screw
5-13	S-266	B/P Fixing Screw
5-14	S-643	E-Crip
5-15	S-238	E-Crip
5-16	S-821	Screw



# WE'RE WORLD WIDE

Come visit us on the Internet at:  
[www.hescoinc.com](http://www.hescoinc.com)