



Models: 6103

	NLA	Motor Unit Assy	62	R-801314	Handle Grip
2	NLA	Carbon Brush Assy	64	R-597743	Screw
3	R-003008	Spring, rear fork	65	R-884708	Eye Bolt
4	R-670013	Screw, motor plate ret.	68	NLA	Handle Adaptor Assembly
5	R-065028	Oiler Cap	75A	R-670844	Cord Clip
6	R-672103	Brush Holder & Screw Assembly	76	R-004723	Spring, handle fork
7	R-311031	Screw & Washer Assembly	77	R-133714	Handle Stop Plate
7A	R-380261	Drive Shaft	79	R-801708	Bolt, handle fork retainer
8	R-618016	Screw, field retainer	80	R-801714	Nut, nylon insert
9	R-608005	Fan, heavy duty	81	R-990104	Screw, handle stop plate
10	R-618772	Spacer, baffle	82	R-028580	Handle, Fork & Latch Assembly
11	R-780002	Field, 120v	88	R-003311	Washer, handle fork clamp screw
12	R-871101	Motor Housing Assembly	89	R-005138	Washer, wheel retainer
13	R-801014	Set Screw, brush holder	90	R-023309	Screw, nozzle & fancase
14	R-801017	Baffle Plate	91	R-230713	Carriage Bolt, handle clamp
15	R-801019	Brush Holder	92	R-2854270	Gasket, nozzle sealing
16	R-801034	Brush Holder Protector Cap	93	R-285720	Wingnut, large
17	R-801701	Screw, rear bearing retainer	96	R-880705	Wide Front Wheel, 2 1/2" diam.
	R-082105	Rear Wheel, Fork & Shaft Assy	97	R-801711A	Wheel Retainer
20	R-880705	Wheel, 2 1/2" diam.	101	R-980743	Screw, machine-thread forming
21	R-801711A	Wheel Retainer	102	R-024961	Nozzle Adjust Screw & Spring
22	R-028574	Rear Fork & Shaft Assembly	102A	NLA	Spring, tension
23	R-080126	Rear Bearing Assembly	105	R-672260	Belt
	R-068007	Motor Plate & Armature Assy	106	R-183749	Side Connection Plate
25	R-175053	Washer, oil slinger	107	R-360753	Screw, side connection plate
26	R-680001	Armature, 120v	108	R-259762	Connector Wire
	NLA	Motor Plate & Bearing Assy	109	R-672270	Nozzle Guard
28	R-880046	Tolerance Ring	110	R-673273	Brush Roll Assembly
29	R-880026	Ball Bearing	119	R-088169	Adjust-O-Rite Plate
30	R-884003	Motor Plate	121	R-880262	Belt Lifter
31	R-080226	Nozzle Assembly	122	R-10343C	Bag Assembly, zipper
38	R-101161	Fancase Assembly	123	R-66247	Paper Bag
	R-099430A	Handle & Cord Assembly	124	R-110773	Insert, motor housing
42A	R-230324	Grommet	125	NLA	Hub Cap
43	R-003311	Washer, adaptor clamp screw			
44	R-023311	Lockwasher			
46	R-801710	Wingnut, small			
47	R-801712	Screw, adaptor clamp			
45	R-801701	Screw, switch plate			
	NLA	Switch & Cord Assembly			
49	R-028537	Cord & Plug Assembly			
50	R-259761	Wire Connector			
51	NLA	Cord Protecting Sleeve			
52	NLA	Short Cord			
53	R-322305	Strain Relief			
55	R-880305	Strain Relief			
56	R-028537	Switch & Plate Assembly			
58	R-0887328	Upper Handle Assembly			
59	R-003884	Spring			
61	R-259318	Upper Cord Hook			